

NOTE

1) INTERIOR VAPOR RETARDER MAY BE REQUIRED IN SOME REGIONS.

2) THIS INFORMATION IS PROVIDED BY DUPONT AS REFERENCE ONLY; PLEASE CONSULT LOCAL BUILDING CODES, REGULATIONS AND LAWS TO DETERMINE THE APPROPRIATE CONSTRUCTION METHODS AND MATERIALS NEEDED.



REVISION DATE: 4/28/10

DRAWING: FA-B-W201s

STOREFRONT WINDOW SILL - METHOD 2

BRICK VENEER / STEEL STUD WALL / SELF-ADHERED FLASHING

