

## NOTES:

- NO LATH FASTENERS AT HORIZONTAL SURFACE, WIRE TIE AS REQUIRED INTERVENING LAYER CAN BE SECOND LAYER OF DUPONT™ TYVEK® WRB, A LAYER OF GRADE D BUILDING PAPER, FELT, RIGID FOAM BOARD OR THE BACKING OF PAPER-BACKED INTERVENING LATER CAN BE SECOND LATER OF DUPONT™ 11VEN WRO, A L LATH.
  REPAIR MINOR HOLES WITH DUPONT™ TYVEK® TAPE.
  FASTEN DUPONT™ TYVEK® WRB WITH APPROVED FASTENERS AND SPACING.

- INTERIOR VAPOR RETARDER MAY BE REQUIRED IN SOME REGIONS.

  LOCAL LAWS, ZONING, AND BUILDING CODES VARY AND THEREFORE GOVERN OVER MATERIAL SELECTION AND DETAILING SHOWN.

  FOR ADDITIONAL INFORMATION REGARDING PRODUCT INSTALLATION, REFER TO THE APPLICABLE DUPONT™ INSTALLATION GUIDELINE.

SCALE: NOT TO SCALE REVISION DATE: 11/1/16 DRAWING: R-CP-1214-MA WALL OFFSET 6" MAXIMUM

CEMENT PLASTER

