

REFER TO THE FACADE CONSIDERATIONS SECTION OF THE APPLICABLE DUPONT INSTALLATION GUIDELINES TO HELP DETERMINE THE APPROPRIATE TYVEK® WRB FOR THE CLADDING TYPE.

²USE OF INTERIOR VAPOR RETARDER IS DEPENDENT UPON CLIMATE ZONE AND LOCAL BUILDING CODES AND LAWS. CONSULT LOCAL JURISDICTION TO ENSURE APPROPRIATE USE OF VAPOR RETARDERS IN WALL ASSEMBLY.

NOTES:

- TAPE ALL TYVEK® WRB SEAMS WITH DUPONT™ TYVEK® TAPE.
- FLASH ALL PENETRATIONS WITH DUPONT SELF-ADHERED FLASHING PRODUCTS.
- FASTEN TYVEK® WRB TO SHEATHING WITH APPROVED FASTENERS AND CORRECT SPACING OF WRAP CAP STAPLES/NAILS (ex. DUPONT™ TYVEK® WRAP CAP FASTENERS).
- DO NOT APPLY TYVEK® TAPE OR DUPONT SELF-ADHERED FLASHING PRODUCTS OVER TYVEK® WRAP CAP
- FASTENERS, OR RECOMMENDED FASTENERS: HOWEVER, FASTENERS CAN BE INSTALLED OVER THE FLASHING.
- LOCAL LAWS, ZONING, AND BUILDING CODES VARY AND THEREFORE GOVERNS OVER MATERIAL SELECTION (ex. SHEATHING TYPE, FRAMING SIZE, INSULATION THICKNESS, ETC.) DETAILING SHOWN ABOVE.

SCALE: NOT TO SCALE

REVISION DATE: 4/19/2022

DRAWING: A21

TYPICAL WALL

RESIDENTIAL WOOD FRAME STRUCTURE w/ WOOD SIDING

