

- THE SECTION DETAILS REFLECT WINDOW FLASHING "AFTER" DUPONT " TYVEK® WRB INSTALLATION. SEE SEQUENCING SHEETS FOR MORE INFORMATION AND OPTIONS. INTERVENING LAYER CAN BE SECOND LAYER OF DUPONT " TYVEK® WRB, A LAYER OF GRADE D BUILDING PAPER, FELT, RIGID FOAM BOARD OR THE BACKING OF PAPER-BACKED.
- INTERVENING LATER CAN BE SECOND LATER OF DUPONT™ 11VEN WRO, A L LATH.

  REPAIR MINOR HOLES WITH DUPONT™ TYVEK® TAPE.

  FASTEN DUPONT™ TYVEK® WRB WITH APPROVED FASTENERS AND SPACING.

INTERIOR VAPOR RETARDER MAY BE REQUIRED IN SOME REGIONS.

LOCAL LAWS, ZONING, AND BUILDING CODES VARY AND THEREFORE GOVERN OVER MATERIAL SELECTION AND DETAILING SHOWN.

FOR ADDITIONAL INFORMATION REGARDING PRODUCT INSTALLATION, REFER TO THE APPLICABLE DUPONT™ INSTALLATION GUIDELINE.

SCALE: NOT TO SCALE REVISION DATE: 11/1/16 DRAWING: R-CP-2111-MA

INTEGRAL FLANGED WINDOW - HEAD

CEMENT PLASTER

