



- $\bullet \ \mathsf{SEAL} \ \mathsf{ALL} \ \mathsf{DUPONT} \ ^{\intercal} \ \mathsf{TYVEK} \ \mathsf{\&} \ \mathsf{SEAMS} \ \mathsf{AND} \ \mathsf{REPAIR} \ \mathsf{MINOR} \ \mathsf{HOLES} \ \mathsf{WITH} \ \mathsf{DUPONT} \ ^{\intercal} \ \mathsf{TYVEK} \ ^{\varrho} \ \mathsf{TAPE}.$
- $\bullet$  FASTEN DUPONT  $^{\rm TM}$  TYVEK  $^{\rm I\!R}$  WITH APPROVED FASTENERS AND SPACING.
- INTERIOR VAPOR RETARDER MAY BE REQUIRED IN SOME REGIONS.
- LOCAL LAWS, ZONING, AND BUILDING CODES VARY AND THEREFORE GOVERN OVER MATERIAL SELECTION AND DETAILING SHOWN ABOVE.
- EXTERIOR INSULATION MAY BE APPLIED IN FRONT OR BEHIND DUPONT ™ TYVEK ® LAYER.

