

- INTERVENING LAYER CAN BE SECOND LAYER OF DUPONT™ TYVEK® WRB. A LAYER OF GRADE D BUILDING PAPER. FELT. RIGID FOAM BOARD OR THE BACKING OF PAPER-BACKED
- LATIT REPAIR MINOR HOLES WITH DUPONT™ TYVEK® TAPE. FASTEN DUPONT™ TYVEK® WRB WITH APPROVED FASTENERS AND SPACING. INTERIOR VAPOR RETARDER MAY BE REQUIRED IN SOME REGIONS.
- LOCAL LAWS, ZONING, AND BUILDING CODES VARY AND THEREFORE GOVERN OVER MATERIAL SELECTION AND DETAILING SHOWN. FOR ADDITIONAL INFORMATION REGARDING PRODUCT INSTALLATION, REFER TO THE APPLICABLE DUPONT™ INSTALLATION GUIDELINE.

SCALE: NOT TO SCALE REVISION DATE: 11/1/16 DRAWING: R-CP-1203-MA

SOFFIT CEMENT PLASTER

