

1) INTERIOR VAPOR RETARDER MAY BE REQUIRED IN SOME REGIONS.

2) THIS INFORMATION IS PROVIDED BY DUPONT AS REFERENCE ONLY; PLEASE CONSULT LOCAL BUILDING CODES, ${\tt REGULATIONS~AND~LAWS~TO~DETERMINE~THE~APPROPRIATE~CONSTRUCTION~METHODS~AND~MATERIALS~NEEDED.}\\$



SCALE: NOT TO SCALE

REVISION DATE: 4/28/10

DRAWING: FA-B-W203s

FLANGED WINDOW SILL - METHOD 2 BRICK VENEER / STEEL STUD WALL / SELF-ADHERED FLASHING

Tyvek. FLUID APPLIED WB