

- INTERVENING LAYER CAN BE SECOND LAYER OF DUPONT™ TYVEK® WRB, A LAYER OF GRADE D BUILDING PAPER, FELT, RIGID FOAM BOARD OR THE BACKING OF PAPER-BACKED
- LATH.

 REPAIR MINOR HOLES WITH DUPONT™ TYVEK® TAPE.

 FASTEN DUPONT™ TYVEK® WRB WITH APPROVED FASTENERS AND SPACING.

 INTERIOR VAPOR RETARDER MAY BE REQUIRED IN SOME REGIONS.
- LOCAL LAWS, ZONING, AND BUILDING CODES VARY AND THEREFORE GOVERN OVER MATERIAL SELECTION AND DETAILING SHOWN. FOR ADDITIONAL INFORMATION REGARDING PRODUCT INSTALLATION, REFER TO THE APPLICABLE DUPONT™ INSTALLATION GUIDELINE.

Tyvek.

SCALE: NOT TO SCALE REVISION DATE: 11/1/16 DRAWING: R-CP-3412-MA

HOLLOW METAL DOOR AFTER WRB - JAMB

CEMENT PLASTER