

1) INTERIOR VAPOR RETARDER MAY BE REQUIRED IN SOME REGIONS.

2) THIS INFORMATION IS PROVIDED BY DUPONT AS REFERENCE ONLY; PLEASE CONSULT LOCAL BUILDING CODES, ${\tt REGULATIONS~AND~LAWS~TO~DETERMINE~THE~APPROPRIATE~CONSTRUCTION~METHODS~AND~MATERIALS~NEEDED.}\\$

SCALE: NOT TO SCALE REVISION DATE: 9/14/10

DRAWING: FA-S-W300s

RECESSED WINDOW SILL

STUCCO / WOOD STUD WALL / FLUID APPLIED FLASHING

