



## STUCCO - CONCRETE COLUMN TRANSITION (METHOD 2)

- SEAL ALL DUPONT ™ TYVEK ® SEAMS AND REPAIR MINOR HOLES WITH DUPONT ™ TYVEK ® TAPE.
- FASTEN DUPONT ™ TYVEK® WITH APPROVED FASTENERS AND SPACING.
- INTERIOR VAPOR RETARDER MAY BE REQUIRED IN SOME REGIONS.
- LOCAL LAWS, ZONING, AND BUILDING CODES VARY AND THEREFORE GOVERN OVER MATERIAL SELECTION AND DETAILING SHOWN ABOVE.

