## **XL5 V5**

## 机架组装示意图 Frame Assembly Guide

1.	M3X28网纹铝柱 M3X28 Al.standoff	x4
2.	M3X20网纹铝柱 M3X20 Al.standoff	x4
3.	M3X8内六角螺丝 M3X8 hex screw	x12
4.	M3X9内六角螺丝 M3X9 hex screw	x16
5.	M3X12内六角螺丝 M3X12 hex screw	x8
6.	M3X14内六角螺丝 M3X14 hex screw	x4
7.	M3X30内六角螺丝 M3X30 hex screw	x4
8.	M3六角尼龙螺母 M3 Nylon nut	x12
9.	M2X4内六角螺丝 M2X4 hex screw	x4
10.	侧板打印件 spacer TPU	x2
11.	Logo打印件 Logo TPU	x1
12.	图传天线座打印件 Antenna/RX TPU	x1
13.	脚垫打印件 Arm Guard TPU	x4
14.	前后保险打印件 Front/Back TPU	x2
15.	顶板 Top plate	x1
16.	中板 Counter plate	x1
17.	机臂 Arm	x4
18.	底板 Bottom plate	x1
19.	侧板 Cam plate	x1

附赠 Additional parts	
<b>20.</b> 915天线座 900 antanna TPU	x1
<b>21.</b> 集线管 50*10 Motor wire protector 50*10	x4
<b>22.</b> 20*250 电池扎带 20*250 Battery strap	x1
<b>23.</b> 20*200 电池扎带 20*200 Battery strap	x1
<b>24.</b> SMA天线棘轮打印件 SMA grip TPU	x1
<b>25.</b> 格纹硅胶电池防滑垫 Battery pad	x2
<b>26.</b> 小天线保护管 Antenna tube	x2
<b>27.</b> 小天线保护管帽 Antenna cap	x2
<b>28.</b> 通用贴纸 Sticker	x1
<b>29.</b> M2X22内六角螺丝 M2X22 hex screw	x4
<b>30.</b> M2六角尼龙螺母 M2 Nylon nut	x4

