AOS LR5 EVO

机架组装示意图

Frame Assembly Guide

1. 顶板 Top plate	x1
·· Top plate 底板	
2. 底板 Bottom plate	x1
3. 机臂	χZ
4. 支架A Counter plate A	x1
5. 支架B Counter plate B	x1
6. 支架C Counter plate C	x1
7. 摄像头侧板 Camera side plate	x1
8. 摄像头硅胶侧板 Silicone camera side plate	x1
9. M2*23 圆形网纹铝柱 M2*23 Al. standoff	X2
10. M3*20 圆形网纹铝柱 M3*20 Al. standoff	x1
11. M3*6 沉头内六角螺丝 M3*6 countersunk hex screw	x8
12. M3*14 沉头内六角螺丝 M3*14 countersunk hex screw	x1
13. M3*6 内六角螺丝 M3*6 hex screw	χZ
14. M2*20 内六角螺丝 M2*20 hex screw	x1
15. M2*8 内六角螺丝 M2*8 hex screw	x1
16. M2*6 内六角螺丝 M2*6 hex screw	χZ
17. M2*5 内六角螺丝 M2*5 hex screw	χć
18. M1.6*10 杯头内六角螺丝 M1.6*10 socket head cap	χZ
19. M2 防松自紧螺母 M2 lock nut	Χć

// (附赠)/(Additional parts)	
1. M3 尼龙螺母 1. M3 nylon nut	x4 ¦
2. M3 防松自紧螺母 2. M3 lock nut	x4
3. M2 尼龙螺母 M2 nylon nut	x8 !
4. M3六角斜花齿压铆螺母 M3 hexagon nut	x2
5. M3*20 内六角螺丝 M3*20 hex screw	x4 !
6. M3 硅胶减震垫片 M3 rubber damper balls	x4
7. M3减震橡胶柱 M3 rubber damper balls	x4
8. 防尘塞 Dust plug	x2
9.15*250 超纤皮电池扎带 15*250 Battery strap	x1
10.15*200 超纤皮电池扎带 15*200 Battery strap	x1
11. 通用贴纸 Sticker	x1
12. 电池硅胶防滑垫 Battery pad	x2
13. M2减震橡胶柱 高6.6 M2 rubber damper balls 6.6	x8 ¦
14. M2减震橡胶柱 高5.6 M2 rubber damper balls 5.6	x8 !
15. 光面硅胶防滑垫 Silicone spacer for 19mm cam	x2

