## XL5 V5 机架组装示意图 Frame Assembly Guide

| 1.  | M3X28网纹铝柱<br>M3X28 Al.standoff | x4   |  |
|-----|--------------------------------|------|--|
| 2.  | M3X20网纹铝柱<br>M3X20 Al.standoff | x4   |  |
| 3.  | M3X8内六角螺丝<br>M3X8 hex screw    | x12  |  |
| 4.  | M3X9内六角螺丝<br>M3X9 hex screw    | x16  |  |
| 5.  | M3X12内六角螺丝<br>M3X12 hex screw  | x8   |  |
| 6.  | M3X14内六角螺丝<br>M3X14 hex screw  | x4   |  |
| 7.  | M3X30内六角螺丝<br>M3X30 hex screw  | x4   |  |
| 8.  | M2X22内六角螺丝<br>M2X22 hex screw  | x4   |  |
| 9.  | M2六角尼龙螺母<br>M2 Nylon nut       | x4   |  |
| 10. | M3六角尼龙螺母<br>M3 Nylon nut       | x12  |  |
| 11. | M2X4内六角螺丝<br>M2X4 hex screw    | x4   |  |
| 12. | 图传天线座<br>Antenna/RX TPU        | x1   |  |
| 13. | 脚垫打印件<br>Arm Guard TPU         | x1   |  |
| 14. | 前后保险<br>Front/Back TPU         | x1   |  |
| 15. | XL5 V5顶板<br>Top plate(2mm)     | x1   |  |
| 16. | XL5 V5侧板<br>Cam mount(1.5mm)   | x2   |  |
| 17. | XL5 V5夹板<br>Counter plate(3mm) | ) x1 |  |
| 18. | XL5 V5机臂<br>Arm(5mm)           | x4   |  |
| 19. | XL5 V5底板<br>Bottom plate(3mm)  | x1   |  |
| 20. | 侧板打印件<br>TPLL spacer           | v2   |  |

