## Chimera4 DC 机架组装示意图 Frame Assembly Guide

<b>1.</b> M2X25网纹铝柱 <b>1.</b> M2X25 Al. standoff	x4
<b>2.</b> M2X7内六角螺丝 <b>2.</b> M2X7 hex screw	x25
<b>3.</b> M2X8圆柱头内六角自攻螺丝 M2x8 Hexagon Socket Self Tapping Screws	x2
<b>4.</b> M2X4内六角螺丝 <b>4.</b> M2X4 hex screw	x4
<b>5.</b> M2X20内六角螺丝 <b>6.</b> M2X20 hex screw	x8
<b>6.</b> M1.6X20内六角螺丝(附赠) <b>6.</b> M1.6X20 hex screw	x4
<b>7.</b> M2尼龙螺母(附赠) <b>7.</b> M2 Nylon nut	x9
<b>8.</b> 4CM小天线保护管(附赠) Antenna tube	x2
<b>9.</b> 小天线保护管帽(附赠) Antenna cap	x2
<b>10.</b> 电机线集线管(附赠) Motor wire protector	x4
<b>11.</b> 电池扎带(附赠) Battery strap	x2
<b>12.</b> 图传天线座 TPU 打印件 Antenna/RX TPU	x1
13. GPS座+T型天线座 TPU 打印件 GPS+T-Type Antenna TPU	x1
<b>14.</b> 摄像头头罩 TPU 打印件 Camera canopy TPU	x1
<b>15.</b> 蜂鸣器 TPU 打印件 Buzzer Mount Stand TPU	x1
<b>16.</b> 脚垫 TPU 打印件 Arm Guard TPU	x1
17. 接收机座 TPU 打印件(附赠) Receiver Mount TPU	x1
18. 顶板 Top plate	x1
19. 底板 Bottom plate	x1
<b>20.</b> 电池防滑垫(附赠) Battery Pad	x2

