Chimera3 机架组装示意图 Frame Assembly Guide

21. 电池扎带(附赠) Battery strap

22. 电池防滑垫 Battery Pad

23. 顶板 Top plate

24. 底板 Bottom plate x2

x2

x1

x1

1. M2X19网纹铝柱 M2X19 Al. standoff	x4
M2XA内六角螺丝	4
2. M2X4 hex screw	x4
3. M2X6内六角螺丝 M2X6 hex screw	x22
4. M2X8内六角螺丝 M2X8 hex screw	x6
5. M2X12内六角螺丝 5. M2X12 hex screw	x4
6. M2X20内六角螺丝 M2X20 hex screw	x4
7. M2X22内六角螺丝 M2X22 hex screw	x2
8. M2尼龙螺母 M2 Nylon nut	x8
9. 避震橡胶O型圈 Rubber O-Ring	x8
10. M3X18内六角螺丝 M3X18 hex screw	x2
11. M3尼龙螺母 M3 Nylon nut	x2
12. 头罩 TPU 打印件 Camera TPU canopy	x1
13. 脚垫 TPU 打印件 Guard TPU	x1
14. 天线尾座 TPU 打印件 TPU antenna mount	x1
15. 915天线座TPU打印件 TBS 915 Antenna Mount	x1
16. 接收机座 TPU 打印件 Receiver TPU mount	x1
17. 透明黑天线固定座(附赠) Transparent black antenna mount	x1
18. 4CM小天线保护管(附赠) Antenna tube	x2
19. 小天线保护管帽(附赠) Antenna cap	x2
20. 电机线集线管(附赠) Motor wire protector	x4

3	23	
11····································		8 1
		9 15 24
13	5 6 7	