



CPU_Supervisor +5٧ U11 Teensy_3.2 USB C3 100nF micro GND 3.6-6 3.3٧ GND U12 GND -⊄CAN_H Si2302CDS SCANH CAN_TX D5 CAN_RX R18 120 6 D6 ×5 Vref CANL 7 D7 EBS_failure_LEDD AS_close_SDC <-A0 -⊲BP1 -dCAN_L SN65HVD230 8 D8 AS_driving_mode <-A1 ⊸3BP2 9 D9 watchdog < A2 ⊲вР3 10 D10 GND SDC_is_readyD-А3 ⊸□BP4 11 D11 (EBS_valve_1_control Α4 -⊲BP5 12 D12 (EBS_valve_2_control Α5 -⊲BP6 R16 220 EBS_valve_1_control EBS_valve_1_outD-10K R19 EBS_valve_1_inD-Q3 Si2302CDS EBS_valves_powerD-Si2302CDS D3 1N4148W GND EBS_valve_2_inD— 10K R20 R17 220 EBS_valve_2_outD-EBS_valve_2_control

Schematics of EBS SDC logic and supervisor CPU Formula Technion Driverless #555

The Technion - Israel Institute of Technology

Sheet: /Suervisor_CPU/ File: Suervisor_CPU.sch

Title: EBS schmatics		Ti	t	le:	Ε	В	S	SC	hmai	ì	ics .	2	0	2	C
----------------------	--	----	---	-----	---	---	---	----	------	---	-------	---	---	---	---

KiCad E.D.A. kicad (5.1.5) – 3	
,	3/3