

## COMPANY PASSENGER VEHICLE PREVENTATIVE MAINTENANCE SCHEDULE

Document No.:	HSE-BF-029
Department:	Operations
Revision Date:	25 AUG 2010
Page	Page 1 of 1

Release authorized by:

D. Slattery

The following maintenance schedule is based on average working conditions. Most of the items listed are checked daily as part of the pre-shift inspection. Shorten the time between maintenance work when operating vehicles:

- a. in consistently high or low temperatures
- b. on extremely rough terrain
- c. in extremely dusty areas
- d. continuously for periods exceeding 8 hours

Also refer to the manufacturers' instructions and adjust the schedule accordingly.

ITEM	MAINTENANCE TASK	MAINTENANCE SCHEDULE	PERSON RESPONSIBLE
1. Air Filter	Check – clean	Twice a week	Operator
	Change	Monthly	Mechanic
2. Belts & Hoses	Check	Daily	Operator
	Change	As needed	Mechanic
3. Brake Fluid	Check	Every two weeks	Mechanic
	Change	As needed	Mechanic
4. Engine	Inspection & Tune-up	Every 6 months	Mechanic
5. Emergency Supplies (first aid, flares, tools)	Check	Daily	Operator
	Replace	As needed	Operator
6. Fire Extinguisher	Check	Daily	Operator
	Change	Every 6 months	Operator
7. Lenses & Lights	Check	Daily	Operator
	Replace	As needed	Mechanic
8. Motor Oil	Check	Daily	Operator
	Change (inc. filter)	Every two weeks	Mechanic
9. Power Steering Fluid	Check	Every two weeks	Mechanic
	Change	As needed	Mechanic
10. Radiator Fluid	Check (when fluid is cold) Change	Daily Annually	Operator  Mechanic
11. Sparkplugs	Check	Every two weeks	Mechanic
	Change	As needed	Mechanic