



DRILL 11/6" to 11/8" dia holes for buttons (outside dia about 17/6")
DRILL 14 dia holes for LEDS
USE mounting holes for alignment

USE 6"x 3" x 2" Radio Shack project enclosure (black plastic)

Bottom hole - dvill 1/4" dia hole 33/4" from left & 3/4" from bottom

FULL SCALE PROJECT BOX BOTTOM TEMPLATE

3/4 -

Battery switch
access hole
1/4" to 3/8" diameter