




P82B715 resistor values can be calculated from the information in the datasheet.



Capacitor values (and sizes) from recommended layout

For each bus section, the pullup resistor is calculated as:

$$R = 1 \mu s / (C_{device} + C_{wiring})$$

where

- C_{device} = Sum of any connected device capacitances
- C_{wiring} = Total wiring and stray capacitance on the bus section



Sheet: /
File: HonkLockSensorBoard.kicad_sch

Size: A4	Date: 2026-08-23	Rev: 1
KiCad E.D.A. 10.0.6		Id: 1/1