LAP-TEQ PLUS Atmosphere — User Manual

TEQSAS PRODUCTS

LAP-TEQ PLUS Atmosphere

User Manual

Contents

1 Before you begin 4
1.1 Intended use 4
1.2 What do the symbols used mean 4
2 For your safety 6
2.1 General safety instructions 6
2.2 Workplace safety 6
2.3 Electrical safety 7
2.4 Safety of persons 7
2.5 Service 7
2.6 Special device instructions 7
3 Product Description 8
3.1 Your device at a glance 8
4 Powering up 9
4.1 Connection 9
4.1.1 Switching on the Atmosphere 9
6 Cleaning 10
7 Issues and Help 11
7.1 Service centre 11
9 Storage 12
10 Disposal 13
11 Technical Data 14
LAP-TEQ PLUS Atmosphere 14
EU Declaration of Conformity 15
Manufacturer 15

1 Before you begin

1.1 Intended use

The LAP-TEQ PLUS Atmosphere is an additional sensor in the LAP-TEQ family for ambient temperature and relative humidity, which can display the sensor values on the LAP-TEQ Display.

The temperature can be displayed in °C or °F. The Atmosphere can be connected directly (without connecting cable) to the LAP-TEQ Display. Other LAP-TEQ sensors can be connected in series. During the start-up process you can choose which sensor you want to see on the respective display options.

Any other use that is not described in these instructions for use is unauthorised misuse. The manufacturer is not liable for any damage resulting from this.

1.2 What do the symbols used mean

Hazard warnings and notes are clearly marked in the instructions for use. The following symbols are used:

DANGER

Immediate danger to life or injury!

Immediately dangerous situation that will result in death or serious injury.

WARNING

Risk of death or injury!

Generally dangerous situation that may result in death or serious injury.

CAUTION

Potential risk of injury!

Dangerous situation that may result in injury.

NOTICE

Risk of damage to the appliance!

Situation that may result in material damage.

> NOTE
>
> Information provided for a better understanding of the processes.

2 For your safety

WARNING!

Failure to observe the safety information and instructions may result in electric shock, fire and/or serious injury!

Read all safety information and instructions.

2.1 General safety instructions

- Keep all safety information and instructions for future reference. The term “appliance” used in the safety instructions refers to mains-powered appliances (with mains cable) and battery-powered appliances (without mains cable).
- Danger to life and accidents for infants and children! Never leave children unattended with packaging material and product. There is a risk of suffocation from packaging material and a risk to life from strangulation. Children often underestimate the dangers. Always keep children away from the product. The product is not a toy.
- To ensure safe handling of this appliance, the user must have read and understood these instructions for use before using the appliance for the first time.
- If you sell or pass on the appliance, it is essential that you also hand over these instructions for use.
- This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and/or knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
- The appliance may only be used if it is in perfect working order and fully assembled. If the appliance or any part of it is defective, it must be taken out of service and repaired or disposed of properly.
- Use the appliance only for the purpose for which it is intended.
- Keep children away from the appliance! Keep the device safe from children and unauthorised persons.
- Only use and store the device within the permissible ambient conditions (temperatures, humidity, etc.).

2.2 Workplace safety

- Keep your work area clean and well lit. Untidiness or unlit work areas can lead to accidents. Observe the workplace and accident prevention regulations applicable in your country.
- Do not work with the electrical appliance in potentially explosive atmospheres containing flammable liquids, gases or dust. Power tools generate sparks that can ignite the dust or vapours.

2.3 Electrical safety

- Static electricity can occur in dry environments. In dry rooms, touch a metal object to discharge the static electricity before operating the appliance.
- Do not misuse the cable to carry or hang up the appliance or to pull the plug out of the socket. Keep cables away from heat, oil, sharp edges or moving parts of the appliance. Damaged or tangled cables increase the risk of damage to the appliance.
- If you use the appliance outdoors, only use extension cables that are also suitable for outdoor use. The use of an extension cable suitable for outdoor use reduces the risk of damage to the appliance.

2.4 Safety of persons

- Be attentive, pay attention to what you are doing and use common sense when working. Do not use the appliance when you are tired or under the influence of drugs, alcohol or medication. A moment of inattention during use can lead to serious injury (e.g. from electric shock).

2.5 Service

- Only have your appliance repaired by qualified specialists and only with original spare parts. This will ensure that the safety of the power tool is maintained.
- Ensure adequate lighting when working with the appliance. Poor visibility can lead to an increased risk of accidents.
- Do not use any accessories that have not been specially designed and recommended by the manufacturer for this appliance. Just because you can connect the accessories to your appliance does not guarantee trouble-free and safe use.
- The device may show signs of wear and tear over time.
- The use of unauthorised accessories may cause damage or wear that is not covered by the warranty.

2.6 Special device instructions

- Do not use the appliance in potentially explosive atmospheres or in the vicinity of flammable liquids or gases!
- If you have an allergic reaction to the colour or metallic parts of the appliance, it may cause itching, eczema or swelling of the skin. If this is the case, stop using the appliance and consult a doctor.
- Do not drop the device and do not subject it to shocks.
- The device or parts of it may be damaged if dropped, bent or deformed.
- Symbols on your device must not be removed or covered. Labels on the appliance that are no longer legible must be replaced immediately.

> NOTE
>
> Read and observe the instructions for use before commissioning.

3 Product Description

3.1 Your device at a glance

Figure 1: LAP-TEQ PLUS Atmosphere – Overview

1. LAP-TEQ Port for additional sensors in daisy-chain operation
2. Output for measurement data
3. Pressure compensation valve for temperature, humidity and pressure sensor

4 Powering up

4.1 Connection

The Atmosphere can be connected directly (without connecting cable) to the LAP-TEQ PLUS Display. Other LAP-TEQ sensors can be connected in series. During the start-up process you can choose which sensor you want to see on the respective display options.

By default, a combination of the measured values of both sensor types is shown in daisy-chain operation.

4.1.1 Switching on the Atmosphere

If only the Atmosphere is to be read out, the switch-on procedure differs slightly depending on the reader device.

LAP-TEQ PLUS Display

1. If only the Atmosphere is connected to the reader unit, the sensor can be started by simply switching on the reader unit.
2. In daisy-chain operation with additional sensors, the Atmosphere can be switched on by pressing and holding the POWER-ON-Taste twice.

LAP-TEQ Motion Remote

1. If only the Atmosphere is connected to the Remote, the sensor can be activated by simply pressing the LAP-TEQ-Taste.
2. In daisy-chain operation, start the Atmosphere by double-clicking the LAP-TEQ-Taste. On the first double-click, PORT-A on the LAP-TEQ Motion Receiver is selected; further double-clicks take you to PORT-B and PORT-C.

6 Cleaning

DANGER!

Danger to life from electric shock!

Disconnect the XLR cable to the display module (power supply) before carrying out any work on the device.

NOTICE!

Risk of damage to the appliance!

Do not immerse the device in water when cleaning, as water can penetrate the electrical system and damage it.

NOTICE!

Possible product damage!

The surface can be damaged. Do not use scratching or abrasive objects or aggressive cleaning agents for cleaning.

- Use a soft, lint-free cleaning cloth dampened with mild soapy water to clean the housing.
- Avoid scrubbing motions on the display window and on the glass window covering the laser outlet.
- Do not use chemicals, cleaning agents or solvents. This can lead to discolouration and corrosion of the outside of the device or result in an electric shock or fire.

7 Issues and Help

> CAUTION!
>
> Risk of injury!
>
> Improper repairs can result in your appliance no longer functioning safely. You are putting yourself and your surroundings at risk.

It is often only minor faults that lead to a malfunction. In most cases, you can easily rectify these yourself. Please refer to the following table before contacting your dealer. This will save you a lot of trouble and possibly also costs.

If the device requires servicing, take it to your sales partner.

Error/Fault	Cause	Remedy
“?.?” appears on the display	The sensor switches off after about 10 minutes because the temperature inside the housing rises during operation.	The device can be restarted after a short while.
Device does not work	Device defective?	Contact service

If you cannot rectify the fault yourself, please contact our service team directly. Please note that improper repairs will also invalidate the warranty and you may incur additional costs.

7.1 Service centre

```
TEQSAS GmbH
Otto-Hahn-Straße 20a
50354 Hürth
Deutschland
Tel.: +49 (0)2233 611-500
E-Mail: service@teqsas.de
```

9 Storage

- Clean and dry all parts and store them in a clean and dry place.
- If you do not use the device for a long time or are transporting it, use the original packaging.

10 Disposal

The packaging is made of environmentally friendly materials that can be disposed of at local recycling centres.

Devices marked with the symbol shown alongside must not be disposed of with household waste. You are obliged to dispose of waste electrical and electronic equipment separately.

You can find out how to dispose of old appliances from your local authority.

By disposing of old appliances separately, you are sending them for recycling or other forms of reuse. In doing so, you will help to prevent harmful substances from being released into the environment.

11 Technical Data

LAP-TEQ PLUS Atmosphere

LAP-TEQ PLUS Atmosphere	
Permissible ambient temperature for use	0 – 40°C
Permissible ambient temperature for storage	−20 – 50°C
Dimensions	102 x 25 x 31mm
Weight	86g

The manufacturer reserves the right to make technical changes to the product / product group without prior notice.

EU Declaration of Conformity

Figure 2: CE

in accordance with EU Directive 2014/30/EU (Electromagnetic Compatibility) of 26 February 2014.

We hereby declare that the device designated below, in its design and construction and in the version placed on the market by us, complies with the essential health and safety requirements of EU Directive 2014/30/EU. This declaration shall lose its validity if the device is modified without our agreement.

Manufacturer

Teqsas GmbH
Otto-Hahn-Straße 20a
50354 Hürth

The manufacturer bears sole responsibility for issuing this declaration of conformity.

Description of the device:

- LAP-TEQ PLUS Display
- LAP-TEQ PLUS Atmosphere

and their identical or similar derivatives.

Conformity is also declared with further directives / regulations / standards applicable to the product, insofar as the product is used in accordance with OStRv 2010 and the corresponding TROS edition 2015.

- RoHS Directive 2011/65/EU of 8 June 2011
- European standard EN 60825-1:2014

The country-specific laser safety conditions must be observed under all circumstances.

Place and date of issue: Hürth, 1 September 2019