SMA, SMB, SMC



Type Code

S **A**

Voltage

Schottky standard:
C = 15 V
E = 30 V
F = 40 V
H = 60 V
J = 100 V

Schottky MBR series
2 = 20 V
3 = 30 V
4 = 40 V
6 = 60 V
9 = 90 V
0 = 100 V

Current
1 = 1 A
X = 1.5 A
2 = 2 A
3 = 3 A
4 = 4 A
--
--

Date Code

X **Y**

Month:
1 to 9 = January to September
A = October
B = November
C = December

Year
(e.g. 1 = 2011, 2 = 2012)