<u>Command Reference</u> > <u>SCPI Command Reference</u> > [<u>SENSe:</u>] <u>Commands</u> > [<u>SENSe:</u>] <u>CORRection...</u> > [SENSe:]CORRection:COLLect:FIXTure:LMParameter:LOSS[:STATe] |

[<u>SENSe:</u>]CORRection:COLLect:FIXTure:LMParameter:LOSS[:STATe] |

Selects an Auto Length or an Auto Length and Loss calculation.

Parameters:

<Boolean> 1 - Auto Length and Loss

0 - Auto Length, no loss

*RST:

Example: See [SENSe<Ch>:]CORRection:COLLect:FIXTure[:

ACQuire]

Manual operation: See <u>"Fixture Compensation"</u>

Top