

DwellLink

User Guide — Resident Connectivity Management, powered by RUCKUS One

Version 1.1.3 — 2026-09-29

Resident Connectivity Management, powered by RUCKUS One.

A guide for front desk staff and property managers using DwellLink day to day. For installation/build details for IT staff, see [README.md](#).

Contents

1. [Opening the app for the first time](#)
 2. [Signing in](#)
 3. [First-time setup \(admin\)](#)
 4. [Managing multiple properties \(admin\)](#)
 5. [Navigation and dark mode](#)
 6. [Managing property units](#)
 - [Bulk actions](#)
 7. [Moving a unit out \(turnover\)](#)
 8. [Importing units from a CSV file](#)
 9. [Exporting units to a CSV file](#)
 10. [Unit & Guest Wi-Fi](#)
 11. [Additional Residents](#)
 12. [Resident directory](#)
 13. [Wi-Fi QR codes](#)
 14. [The resident portal link](#)
 15. [Connected devices](#)
 16. [Staff accounts \(admin\)](#)
 - [Restricting front desk access to specific properties](#)
 17. [Audit log \(admin\)](#)
 18. [Security: auto sign-out \(admin\)](#)
 19. [Software updates \(admin\)](#)
 20. [Appearance \(admin\)](#)
 21. [Backup & Restore \(admin\)](#)
 22. [Troubleshooting](#)
-

Opening the app for the first time

This app isn't distributed through the Mac App Store, so the first time you open it, macOS will likely warn that it's "from an unidentified developer."

1. Copy **DwellLink.app** to your **Applications** folder (or open it straight from the installer `.dmg`).

2. **Right-click** (or Control-click) the app icon and choose **Open**.

3. Click **Open** again in the dialog that appears.

You only need to do this once — after that, it opens normally by double-clicking like any other app.

If macOS says the app "is damaged and can't be opened," it usually means the file lost its safety approval in transit (e.g. it was zipped and emailed). Ask whoever built the app to re-share it, or see your IT contact.

Signing in

Each staff member should have their own account. Enter your **username** and **password** on the sign-in screen and click **Sign in**.

You can change your own password any time from **Settings → Change your password**. If you're locked out, ask an admin to reset it for you from the **Staff** tab — see [Staff accounts](#). After an admin-initiated reset, you'll be asked to set your own new password immediately after signing in with the temporary one, before you can do anything else in the app.

First-time setup (admin)

If this is a brand new install, you'll see a **Welcome** screen instead of a sign-in form — no staff accounts exist yet. Create the first one here; it's automatically a property manager (admin) account.

Once signed in, go to **Settings**:

1. Under **RUCKUS One API connection**, fill in the Tenant ID, Client ID, and Client Secret (RUCKUS One → Administration → Account Management → Settings → create an Application Token), and click **Save connection settings**.
2. Under **Properties**, click **+ Add Property**, then **Load from RUCKUS One** to populate the dropdowns — pick your building, its DPSK Pool (the one linked to your venue is marked "recommended"), and its Wi-Fi network (SSID). Click **Add property**.

The app is now ready to use. See [Managing multiple properties](#) if you look after more than one building.

Managing multiple properties (admin)

One DwellLink install can manage several RUCKUS venues ("properties") — useful if you're a property manager across more than one building. The sidebar always shows which property you're currently working in, under the logo.

Under **Settings → Properties**:

- **+ Add Property** — connect another RUCKUS venue, the same way as [first-time setup](#): pick the venue, its DPSK Pool, and its Wi-Fi network.
 - **Set active** — switches the *entire app* to that property — Units, Directory, Additional Residents, everything. Front desk staff see whichever property is currently active; they can't switch it themselves. The sidebar's property dropdown (visible once you have 2+ properties) does the same thing without leaving whatever screen you're on.
 - **Edit** — change a property's DPSK Pool or Wi-Fi network, or rename how it appears in DwellLink (this doesn't rename anything in RUCKUS One itself).
 - **Remove** — stops DwellLink from managing that property. This only affects this install; nothing changes in RUCKUS One.
-

Navigation and dark mode

The left sidebar is how you move between **Units**, **Directory**, **Staff** (admin only), **Audit Log** (admin only), **Settings**, and **Help**. At the bottom of the sidebar, the light/dark switch toggles the whole app's theme — it's remembered per device, not shared across staff accounts.

If you manage 2+ properties, the property name at the top of the sidebar becomes a dropdown you can use to switch properties directly, without going into Settings (see [Managing multiple properties](#)).

A small number badge appears on the **Directory** tab whenever any resident's access is expiring within the next 7 days — a heads-up to check the Directory's [Expiring soon](#) filter without having to click in first.

Managing property units

The **Units** tab is the home screen — every unit and conference room in the building, with quick counts at the top (total, active, suspended, conference rooms), a search box, and filter chips to narrow the list to just units or just conference rooms.

The first time you sign in, this list is fetched live from RUCKUS One and can take a little while to populate — a spinner and "Loading units from RUCKUS One..." message show while it's working, rather than the screen just looking empty.

- **+ Add Unit** — create a new residential unit. Fill in the unit name/number and the resident's name (required), plus email and phone (optional, used for Wi-Fi credential notifications and account contact).
- **+ Add Conference Room** — same form, but the unit is created as a conference room instead of a residential unit. This can't be changed later, so pick the right button up front.
- **Search** — matches unit name, resident name, email, or phone number. Try searching an email address to find which unit a person lives in.
- Click any row to open that unit's detail page.
- Conference rooms show a blue **Conference room** tag next to their name in the list, so they're easy to tell apart from residential units at a glance.

Bulk actions

Check the box next to any unit (or **select all** in the header) to reveal a bulk actions bar for everything currently checked:

- **Resend access details** — re-sends each selected unit's Wi-Fi credentials by email/SMS, same as doing it one at a time from each unit's page.
- **Move-in sheets** — click to choose how you want a move-in Wi-Fi sheet (logo, unit, resident name, QR code, network name/password) for every selected unit:
 - **Print** — sends them all to your printer as one job, one page per unit.
 - **Save as one PDF** — the same sheets as a single PDF file with one page per unit, e.g. to file away or hand off as one document.
 - **Save as separate PDFs** — the same sheets as individual PDF files, one per unit, e.g. to email each resident their own sheet.

All three are handy for a whole batch of welcome packets for a new building or a bulk move-in day, instead of opening each unit individually. A unit with no Wi-Fi network configured or no passphrase set yet is skipped in any of the three, and you're told which ones and why so nothing silently goes missing from the batch.

- **Suspend / Reactivate** — temporarily disable or re-enable every selected unit.
- **Delete** (admin only) — permanently deletes every selected unit. This cannot be undone in RUCKUS One.

Each action runs across the whole selection and reports how many succeeded if any individual one failed, rather than stopping at the first problem.

On a unit's detail page

- **Save changes** — updates the unit name and resident contact info.
- **Resend access details** — has RUCKUS One re-send the resident's Wi-Fi passphrase and resident portal link by email/SMS. Useful if a resident says they never got their welcome message, or lost it.
- **Suspend unit / Reactivate unit** — temporarily disables the unit without deleting it.
- **Move out / Turnover** (admin only) — see [Moving a unit out](#) below.
- **Delete unit** (admin only) — permanently removes the unit from RUCKUS One. This cannot be undone.
- **Type / Category / PMS unit ID** — shown as read-only text if set; RUCKUS doesn't allow changing these after a unit is created.

Moving a unit out (turnover)

When a resident moves out, **Move out / Turnover** (admin only, on the unit's detail page) does the whole handoff in one step instead of several manual ones:

- Revokes the unit's owner and guest Wi-Fi access (the departing resident's login stops working immediately).
- Removes and deletes every Additional Resident on the unit.
- Clears the resident name, email, and phone so the unit is ready for the next tenant's info.

It does **not** suspend the unit itself — a vacant unit between tenants isn't the same as a suspended one, so suspend separately if you actually need to. This cannot be undone; confirm you have the right unit before clicking through the warning.

Importing units from a CSV file

For move-in day or setting up a whole building at once, use **Import CSV** on the Units tab instead of adding units one at a time.

1. Click **Import CSV**.
2. Click **Download CSV template** to get a starter file with the right column headers.
3. Fill it in in Excel/Numbers/Google Sheets — one row per unit:

Column	Required?	Notes
name	Yes	Unit name/number, or room name for a conference room
resident_name	Yes	Resident's or contact's name
resident_email	No	
resident_phone	No	
category	No	UNIT (default) or CONFERENCEROOM
pms_unit_id	No	Your property-management-system's own unit ID, if you track one
vlan	No	Owner Wi-Fi VLAN (1-4094)
description	No	Owner Wi-Fi description
passphrase	No	Owner Wi-Fi passphrase (8-63 characters). Leave blank to set one later from the unit's page instead
guest_vlan	No	Guest Wi-Fi VLAN (1-4094) — only applies if this property has guest Wi-Fi configured
guest_passphrase	No	Guest Wi-Fi passphrase (8-63 characters)

4. Save as **.csv** and select it in the app. You'll see a **preview** of everything about to be created, including a **Wi-Fi** column summarizing any VLAN/passphrase values — check it before importing. Rows missing a required column are automatically skipped and listed so nothing silently fails; an out-of-range VLAN or too-short passphrase doesn't skip the whole row, just that one value (also called out in the preview), since the unit and resident are still good without it.
5. Click **Start import**. Units are created one at a time with a live progress list; if one row fails (e.g. an invalid phone number format), the rest keep going and the failure is reported clearly instead of stopping the whole batch. VLAN/description/passphrase values finish applying in the background a few seconds after each unit

is created (RUCKUS processes unit creation asynchronously), so they may not be set yet the instant the row shows "created."

Exporting units to a CSV file

Export CSV on the Units tab downloads every currently-listed unit (name, category, resident contact info, status, and RUCKUS ID) as a spreadsheet — for record-keeping, reporting, or moving data elsewhere. The first six columns match the import template exactly, so a trimmed export can be edited and re-imported unchanged.

Unit & Guest Wi-Fi

Every unit has two built-in Wi-Fi logins, shown together with the unit's Details on its detail page:

- **Unit (owner) Wi-Fi** — the resident's own passphrase.
- **Guest Wi-Fi** — a separate passphrase for their guests, if the venue has guest Wi-Fi configured.

For each, you can view/edit the **Passphrase**, **VLAN**, and **Description**, see which devices are currently connected under it, and:

- **Save details** — saves passphrase/VLAN/description changes.
 - **Generate new passphrase** — immediately replaces the current passphrase with a new one (the old one stops working). Matches whatever passphrase format the property's DPSK service is configured for (e.g. numbers-only, dictionary words) rather than a generic random string.
 - **QR code** — shows a scannable Wi-Fi QR code for that passphrase (see [Wi-Fi QR codes](#)).
-

Additional Residents

For units with more than one person needing their own separate Wi-Fi login (roommates, etc.), use the **Additional Residents** table on the unit's detail page.

- **+ Add Resident** — creates a new resident with their own name, email, phone, VLAN, description, and expiration date, and their own Wi-Fi passphrase.
- **Edit / QR** (each row) — change a resident's details, or get a scannable Wi-Fi QR code for their passphrase.
- Select one or more residents with the checkboxes to reveal bulk actions: **New passphrase**, **Revoke / Unrevoke**, and (admin only) **Remove** — handle several residents (e.g. a whole roommate group moving out) in one action instead of one at a time.

The **Devices** column shows what's actually connected right now under each resident's login — this is live data from RUCKUS One, refreshed each time you open the unit.

Resident directory

The **Directory** tab lists every unit's **owner** (the resident of record) and every **Additional Resident**, across the whole property, in one place — useful for "a resident calls in, who are they and which unit" without opening each unit one by one. The **Type** column tags each row Owner or Resident so the two aren't confused.

- **Search** — matches name, email, phone, unit, or description, across both owners and residents.
 - **Expiring soon** — shows only residents whose access expires within the next 7 days (owners don't have an expiration date, so they're never included here).
 - **Revoked** — shows only currently-blocked residents (same — owners aren't tracked as revocable here).
 - Click any row to jump straight to that person's unit. If the row belongs to a different property than the one you're currently in, DwellLink switches to that property first.
 - **Search across all properties** (admin, only shown once you manage 2+ properties) — expands the list to every property at once, adding a **Property** column so you can tell rows apart. Handy when a resident calls in and you're not sure which building they're in.
 - **Export CSV** — downloads whatever's currently shown (respecting the search box and any active filters) as a spreadsheet, including the Property column when searching across properties.
-

Wi-Fi QR codes

Any QR code shown in the app (owner, guest, or additional resident) can be scanned directly with a phone camera to join Wi-Fi automatically, or downloaded as a PNG image (**Download** button in the QR window) — handy for printing a welcome card or including in an email.

For a ready-to-hand-over move-in sheet, use the two buttons next to Download:

- **Print move-in sheet** — opens your printer dialog with a one-page sheet: property logo, unit, resident's name, the QR code, and the Wi-Fi network name/password spelled out — nothing else from the app is included on the page.
- **Save as PDF** — generates the same sheet as a PDF file you can email or save, without needing to go through a printer dialog.

Need sheets for several units at once (a new building, a bulk move-in day)? Select them from the Units list instead — see **Bulk actions** — which can print them all in one job, save them as one combined PDF, or save one PDF per unit, rather than doing them one at a time here.

The resident portal link

Each unit has a **Resident portal link** on its Details card — a direct link to that resident's self-service portal in RUCKUS One, where they can view their own Wi-Fi details and manage their own connected devices.

- **Copy link** — copies it to your clipboard to paste into an email or message.

- **Open** — opens it in your default web browser.
-

Connected devices

The **Connected devices** card on a unit's page shows every device currently on Wi-Fi under that unit (owner, guest, or any additional resident). Click **Check status** to refresh it.

For each connected device:

- **Details** — full information: hostname, operating system, IP address, which access point it's connected to, signal health, and how long it's been connected.
 - **Remove from network** — disconnects that device right now. Note this is a one-time kick — the device can reconnect on its own afterward unless you also block the identity (below).
 - **Block identity** — revokes that resident's entire Wi-Fi passphrase, blocking *all* of their devices, not just the one you clicked from. RUCKUS doesn't support blocking a single device permanently — blocking the identity is the only real way to keep someone off Wi-Fi going forward.
-

Staff accounts (admin)

The **Staff** tab (admin only) lists everyone with access to the app.

- **+ Add Staff Account** — create a new login, choosing **Front desk** (day-to-day unit/resident management) or **Property manager (admin)** (everything, plus staff accounts, settings, and unit deletion). For a front desk account, check off which properties they should have access to — see [Restricting front desk access to specific properties](#) below.
- **Edit access** (front desk accounts only) — change which properties an existing account can see and manage, without having to recreate it.
- **Reset password** — generates a new temporary password for that person and shows it to you once so you can share it with them directly (it won't be shown again). They should change it from Settings after signing in. You can't reset your own password this way — use **Settings → Change your password** for that.
- **Delete** — remove an account (you can't delete your own).

Each staff member should have their own account rather than sharing one — actions are logged per username.

Restricting front desk access to specific properties

If your team runs multiple properties from one shared workstation, you can limit each front desk account to only the buildings it should work with — they won't see, search, or manage any property outside that list, and properties they don't have access to don't show up anywhere in the app for them (not just the switcher — the Directory, Units, and everywhere else too).

- When adding or editing a front desk account's access, check the properties it should be able to use. Leaving all boxes unchecked means that account can't do anything until access is granted.

- A front desk account assigned 2+ properties gets its own sidebar quick-switcher (same as an admin's), scoped to only the properties it's allowed to use.
 - Property managers (admin) are never restricted — they always have access to every property, and this doesn't apply to them.
 - If the shared workstation's currently-active property isn't one a signing-in front desk account has access to, DwellLink automatically switches them to one they do have access to rather than showing an error.
-

Audit log (admin)

The **Audit Log** tab (admin only) shows every account and RUCKUS-affecting action taken in the app — unit and resident changes, staff account changes, settings changes, sign-ins, and more — most recent first, with who did it and when. It shows the last 1000 entries.

- **Search** — filters by username, action, or anything in the detail.
 - **Action filter** — narrows to one type of action.
 - Click any row to see its full detail.
 - **Export CSV** — downloads the currently loaded log as a spreadsheet.
 - **Refresh** — reloads the latest entries.
-

Security: auto sign-out (admin)

Under **Settings → Security**, set how many minutes of inactivity (no mouse or keyboard use) before the app automatically signs out — useful for a shared front-desk terminal. This applies to every account on this install, including admins. Set it to **0** to disable auto sign-out.

Software updates (admin)

Under **Settings → Software Updates**, click **Check for updates** to see whether a newer build of the app is available and what version you're currently running. If one exists, **Download update** opens the download page — updates aren't installed automatically; download and run the new installer yourself, the same way you installed this one.

Appearance (admin)

Under **Settings → Appearance**, customize the app for your property:

- **App name** — replaces "DwellLink" throughout the app.

- **Logo** — shown on the sign-in screen and in the top bar. Upload a PNG, JPEG, SVG, or WebP file.
- **Primary color / Accent color** — used for buttons, highlights, and the active tab indicator.
- **Login screen message (optional)** — a short note (up to 500 characters) shown to staff below the logo on the sign-in screen, e.g. "Building office closed Dec 25 - Jan 1." This is only visible on the sign-in screen and is never sent to residents — see [Resident directory](#) and the note on resident announcements in Troubleshooting if you're looking to notify residents instead.

Changes apply immediately and to every staff account using this installation (it's a setting for the install, not per-user). **Reset to default** restores the original RUCKUS branding.

Backup & Restore (admin)

Under **Settings → Backup & Restore**:

- **Export config backup** — downloads a JSON file with this install's RUCKUS connection settings, venue/DPSK/network selection, and appearance. Useful before making changes you might want to undo, or when setting up a second workstation with the same configuration.

This file contains your RUCKUS API client secret in plain text. Store it somewhere secure — a password manager, not a shared drive or email — the same way you'd protect any other credential.

- **Restore from backup file** — pick a previously exported file to restore all of the above. You'll be asked to confirm, since this overwrites your current settings.

This does **not** back up your property units, residents, or anything else stored in RUCKUS One itself — only this app's own local configuration. Your actual property data always lives in RUCKUS One.

Troubleshooting

"RUCKUS One API credentials are not configured yet" Go to Settings and fill in the Tenant ID / Client ID / Client Secret under RUCKUS One API connection, then Save.

A unit I just created doesn't show up immediately RUCKUS One processes new units in the background; click **Refresh** on the Units tab after a few seconds if it doesn't appear right away.

"Changing unit category is not supported" Type and category can only be set when a unit is first created (via the right button: Add Unit vs. Add Conference Room) — RUCKUS doesn't allow changing them afterward.

A resident's passphrase/VLAN change didn't seem to save Some fields on this API take a few seconds to apply in RUCKUS One even though the app shows success right away. Re-open the unit after a moment to confirm.

Search isn't finding someone Search matches unit name, PMS unit ID, resident name, email, and phone — check for typos, or try searching just part of the name or a full email address.

I don't see the Staff/Settings tabs, or can't delete a unit Those require a **Property manager (admin)** account — a Front desk account won't have them. Ask an admin to either do it for you or upgrade your role.

Can I send a custom announcement to owners/residents? Not through RUCKUS One's API today — the only resident-facing notification it exposes is a fixed, RUCKUS-templated Wi-Fi credential email/SMS (**Resend access details**), with no field for custom text. RUCKUS does have one passive option: a per-property "announcement" banner shown on the resident self-service portal itself (not pushed via email/SMS — residents only see it if they open the portal), which isn't currently exposed in DwellLink. Sending genuinely custom messages (email/SMS/push) to residents would need a separate integration outside RUCKUS One entirely.