

DC-12V INPUT
F1 2A
D1
U12
LOCAL SERVICE
GND SDA SCL
J18
3V3 OUT
GND
+3V3
SDA
SCL
I2C_5
C68 C69
U13
R82
R84
R83
HOST 3V3 IN
QWIC SENSOR
QWIC MASTER
RheoBoard v1.05