LG LD-2131SH Dishwasher Drain Pump Replacement

LONGLIBRALOU and one other contributor
Last updated on Sep 1, 2022

Introduction Go to step 1 ↓

Hi there!

Today weawel you since I had to wait for a new pump kit wit replace the Drain Pump on an LG LD-2131SH Dishwasher. Let's go!

https://www.ifixit.com/Guide/LG+LD-2131SH+Dishwasher+Drain+Pump+Replacement/151113 Here **is a nice quick video on hand safety! Thanks to** Safety Mantra**!**

Step 1 Identify Machine and Drain Pump

- Apologies in advance for the poor pictures :P
- The photo shows the OEM part. I will replace it with a "generic" part. Inlead in the "Parts" area, and also below.
- https://www.rakatstol.com/universal-washi...

Add a comment

Step 2 Tools

- The main tools I forgot to put the zip tie and clipper there, sorry :P)
- NOTE: make notes of where screws are removed. I have gotten mixed up and spent many hours trying to sort them out - with poor success rate thus far :(
- Make sure the machine is unplugged/disconnected from 'Electrical energy source before commencing!'
- Also remember to shut off and disconnect the water supply and drain hose :)

Add a comment

Step 3 Interior

- Remove and un-clip the regular maintenance parts from interior.
- Red circle: Also remove the vent plug on the side.
- Hand Safety: Machine has stamped metal parts - take care not to cut yourself!

Add a comment

Step 4 Tub/Sub flange

- 1st pic: remove the 4 screws that retain the discharge manifold (grey part).
- 2nd pic: remove the clips that clamp the machine drum to the sub assembly.
- NOTE: make notes of where screws are removed. I have gotten mixed up and spent many hours trying to sort them out - with poor success rate thus far :(

Add a comment

Step 5 Door

- Now we disassemble the door. There are 10 screws around the circumference of the door, holding the front panel to the inner door panel of the door. Remove them. (sorry I have lost the proper picture)
- Make a note of where what wires go, and undo the harness.
- Door front panel is separated, clean and set aside.
- NOTE: there is a plastic shroud below the door - it unclips easily - remove that too.
- NOTE: make notes of where screws are removed. I have gotten mixed up and spent many hours trying to sort them out - with poor success rate thus far :(
- Hand Safety: Machine has stamped metal parts - take care not to cut yourself!

Add a comment

Give the Gift of Repair
Gifts they'll use, skills they'll keep.
Up to 20% Off Tools

Step 6 Top panel

- Unscrew indicated screws and slide top of machine towards the back, clean and set aside.
- NOTE: make notes of where screws are removed. I have gotten mixed up and spent many hours trying to sort them out - with poor success rate thus far :(

Add a comment

Step 7 Side panels

- Undo all the screws holding the two side panels in place.
- Both panels remained hanging there after all the screws were out, which makes for easy work, thanks random engineer at LG!
- Anyways, lift panels off, clean and set aside.
- NOTE: make notes of where screws are removed. I have gotten mixed up and spent many hours trying to sort them out - with poor success rate thus far :(
- Hand Safety: Machine has stamped metal parts - take care not to cut yourself!

Add a comment

Step 8 Ballast Weight

- I removed the ballast weight to ease handling of the tub.
- NOTE: make notes of where screws are removed. I have gotten mixed up and spent many hours trying to sort them out - with poor success rate thus far :(
- Hand Safety: Machine has stamped metal parts - take care not to cut yourself!

Add a comment

Step 9 Tub/Sub separation

- Here we go! at separating the tub from the sub-assembly. Remove screws as shown.
- Red arrows: screws.
- Yellow arrows: screws on front side of machine
- Green arrows: Earth Wires.
- NOTE: make notes of where screws are removed. I have gotten mixed up and spent many hours trying to sort them out - with poor success rate thus far :(
- Get someone to assist with lifting the tub off-very carefully, while constantly checking for any snags etc. Once tub is removed, clean and set aside.
- Hand Safety: Machine has stamped metal parts - take care not to cut yourself!

Add a comment

Step 10 Unhooking the Sub-assembly

- Red arrows: screws - the screw holding the harness guide in place is accessed from the front of the machine.
- Green arrows: unplug/disconnect
- Purple circle: clip the zip tie
- Green circle: next photo
- Yellow arrows: flow sensors - they unclip from the housing or if you, rather don't want to - they also have small connectors that you can unplug.
- Light Blue circle: pull the pipes out from the housing - it is quite hard, but slow and steady wins the race. Wiggling helps too.
- Dark Blue circles: undo the clips using pliers, I just moved the clips about an inch up the hose, easy storage spot. Then just wiggle the hoses off.
- Carefully remove the harness, clean and set aside.

Add a comment

Step 11 Removal of component assemblies

- 1st pic: circles show where I had my hands when lifting the salt bucket and water manifold out.
- 2nd pic: arrow points to the rubber foot that we need to wiggle free when lifting the plumbing assembly out of the frame.
- 3rd pic: Again position of my hands when pry lifting the assembly out.
- Please take care not to spill too much of the "grey water" trapped in the assembly onto anything you would not want it on.

Add a comment

Step 12 Pump Removal

- 1st pic: Undo the screws and pull pump out of housing
- 2nd pic: I just flipped the pump over to show the impeller.
- NOTE: This is the second kit I've had to replace. The first time around I found that the impeller was broken in the pump. No idea where it came from though. And also I assume it caused some uneven damage(more on this later).

Add a comment

Step 13 Testing (for interest sake)

- **DO NOT DO THIS - ELECTRICAL HAZARD**
- Testing revealed fluctuating vibrations, kind of like "speed wobbles", indicating well worn bushes).
- This can point to the rotor being forced out of line(alignment) while being mechanically stuck(the small magnet of earlier). Judging by the soft appearance of the bushin(ie pic sorry) I would give this theory a solid "most likely"
- Prying the rotor from the housing reveals nothing further of interest. Spinning the rotor by hand, it spins smoothly with no resistance, and through the ammo-dapter (Magnetic Driver), poses no electrical risk. This also removes the need for a shaft seal. Sound Engineering!
- The video clip is a "super slo-mo" shot with a Samsung Galaxy S20fe. It shows the speeding up and slowing down of the pump. If I take the noise it makes into consideration, this is not normal. "I may obviously be wrong"

Add a comment

Step 14 Testing (pics)

- Added this step to add pictures that relate to Step 13.
- Electrical Hazard: Testing these things obviously need some knowledge.
- **ELECTRICITY CAN KILL YOU**

Add a comment

Step 15 Assembly

- The assembly should be the reverse of what we have done. However, I will update with any significant findings, if any occur, since I have the new pump and start assembling.
- Hand Safety: Machine has stamped metal parts - take care not to cut yourself!

Add a comment

Author
with 1 other contributor
LONGLIBRALOU
Reputation Since: 07/29/20
241 Reputation
1 Guide authored
Badges 2

View Statistics Past 24 Hours 2 Past 7 Days 17 Past 30 Days 70 All Time 2,427