



AC Analysis with Multisim

1. Complete the schematic.




2. Under Options/ Sheet visibility/ Net Names select Show all.



3. Label the input and the output nodes




- a. Right click on the node.
- b. Select Properties.

Complete the Preferred net name box
Chose Red for the color.



4. Select Simulate.

- a. Analysis AC Analysis
- b. Complete the data fields as shown below.
- c. Select Simulate at the bottom of that box.




5. Presentation

- a. Reverse the colors to give a white background
- b. Select **Show Grid**
- c. Select **Show Cursors** – drag the cursor to a key spot



- d. Move the cursor to each key location and add a data label.
- e. Add **Data label**.



6. Use the Windows snip tool to capture the display.