# Test Print

This machine is now ready for printing.

Quick Menu for smooth access to Canon's web service and to various functions for photo printing and video printing.

(1) Shortcut Menu

(2) Image Display

(1) Shortcut Menu

(2) Image Display

After this, Quick Menu opens automatically.

When you click the [CREATIVE PARK PREMIUM icon] (CREATIVE PARK PREMIUM) icon on the shortcut menu, My Image Garden opens. You can then download printables of popular characters or famous artists and print them.

*CREATIVE PARK PREMIUM is a premium content service available exclusively to customers who use genuine Canon ink for all colors. To use this service, you must have My Image Garden installed on your computer.

When My Image Garden is installed, Image Display also opens.

Image Display displays a slide show of artwork images that were created automatically by the recommended artwork functions of My Image Garden, as well as other images saved on your computer.