TR-09 // VEHICLE EMERGENCY PREP

1. PHASE ALPHA: INSTANT VEHICLE MOBILIZATION ('OMG WE HAVE TO EVACUATE NOW!!!')

■ **HIGH-SPEED CRANKCASE OIL DIPSTICK TRACE:** Pull dipstick, wipe clean, re-insert, and read level. Verify fluid sits between cross-hatched marks. If low, pour 1 full quart of multi-weight engine oil (5W-30).

■ **THE BATTERY TERMINAL CORROSION SCRAPING:** If white/green powdery structures wrap around posts, engine will fail to start. Use a wire brush or metal tool to scrape metal down to bare material. Tighten nuts securely.

■ **ENGINE COOLANT LEVEL SAFETY CHECK:** Look at translucent overflow tank. Verify fluid rests at FULL COLD mark. Ensure a proper 50/50 mix of ethylene glycol and distilled water. CRITICAL MANDATE: Never open hot cap.

2. PHASE BRAVO: LONG-TERM PLANNING & SYSTEM PRESERVATION

■ **THE EXTENDED FUEL STABILIZATION STORAGE RULE:** Add exactly 1 ounce of chemical fuel stabilizer per 2.5 gallons of gasoline directly into the tank. Run engine for 5 minutes to pull stabilized fuel through lines.

■ **THE NEGATIVE TERMINAL DISCONNECT:** Disconnect the black negative (-) battery cable from the terminal post to stop electrical drain over a 3-week storage period. Wrap loose cable end in a dry cloth.

CRITICAL PANEL / REFERENCE REGISTER

Private mechanical adjustments are field resilience aids only. The user assumes all physical liability for roadside fixes. Always park on a level, solid surface and engage the parking brake before executing engine compartment traces.

AUTHORITATIVE REFERENCES: National Highway Traffic Safety Administration (NHTSA) Vehicular Safety Standards, Automotive Maintenance Excellence Guidelines.