STEP	ACTION	BY	CHECK	INIT
	SWITCHOVER (SITE A TO SITE B)			
1	Announce drill / switchover on the phone bridge. Log start time (UTC).	LEAD	MANUAL	
2	Confirm last archive replication completed.	ENG	MANUAL	
3	Site B: start generator under load. Confirm UPS on line.	SITE B	MANUAL	
4	Site B room staffed: Lead and six consoles.	SITE B	MANUAL	
5	Hand-over: Site A Lead reads open items; Site B Lead repeats back. Bridge order: Leads, then consoles in seat order.	LEAD	MANUAL	
6	Node transfers redirected to Site B ingestion. Confirm all eight nodes reporting.	ENG	MANUAL	
7	Site B Lead takes the watch. Log time (UTC). Site A consoles to standby.	LEAD	MANUAL	
8	Check all node links up.	ENG	MANUAL	
	SWITCHBACK (SITE B TO SITE A)			
9	Confirm Site B records copied to Site A.	ENG	MANUAL	
10	Hand-over Site B Lead to Site A Lead (as step 5).	LEAD	MANUAL	
11	Node transfers back to Site A. Confirm all eight nodes reporting.	ENG	MANUAL	
12	Site A Lead takes the watch. Log time (UTC). Site B to standby; generator cool-down.	LEAD	MANUAL	
13	Drill report: times, problems, open items to the maintenance log within 24 h.	LEAD	MANUAL	

TARGET: SITE B HOLDS THE WATCH WITHIN 45 MIN OF STEP 1. TIMES RECORDED IN THE WATCH LOG.

PROCEDURE

SUPERSEDED
SEE REGISTER FOR CURRENT REVISION

REVISIONS

REV	DATE	DESCRIPTION	BY	APPR
B	10 APR 2000	Hand-over timing and phone bridge order revised.	DO	RS
A	06 DEC 1999	Initial issue.		

NOTES

1. Used for the quarterly drill and for any real switchover. Drill dates set by engineering with the watch Leads.
2. Times in UTC. Each step initialled on the printed copy.
3. Site B layout per SITE-B-001, power per PWR-002, links per NET-002.
4. If any check fails, stop and stay on the current site; Lead decides whether to continue.

OER // ENGINEERING

SWITCHOVER AND SWITCHBACK PROCEDURE

DRAWING NO.	REV	SHEET
SITE-B-002	B	1 OF 1

DRAWN	CHECKED	APPROVED
D. OKAFOR	T. MERCER	R. SHAW

DATE	SERIES
10 APR 2000	SITES

CONTROLLED DOCUMENT // CUSTODIAN: ENGINEERING / MAINTENANCE // DO NOT SCALE