## PROCEDURE

| STEP | ACTION | BY | CHECK | INIT |
|---|---|---|---|---|
| | **SWITCHOVER (SITE A TO SITE B)** | | | |
| 1 | Announce drill / switchover on the phone bridge. Log start time (UTC). | LEAD | MANUAL | |
| 2 | Confirm replication current: archive and record store lag under 5 min. | ENG | AUTO | |
| 3 | Site B: start generator under load. Confirm UPS on line. | SITE B | MANUAL | |
| 4 | Site B watch floor staffed: Lead, all console positions. | SITE B | MANUAL | |
| 5 | Hand-over: Site A Lead reads open items; Site B Lead repeats back. Bridge order: Leads, then consoles in seat order. | LEAD | MANUAL | |
| 6 | Node transfers redirected to Site B ingestion. Confirm all eight nodes reporting. | ENG | AUTO | |
| 7 | Site B Lead takes the watch. Log time (UTC). Site A consoles to standby. | LEAD | MANUAL | |
| 8 | Check link encryptors in service on all node links (NET-007). | ENG | AUTO | |
| | **SWITCHBACK (SITE B TO SITE A)** | | | |
| 9 | Replication check Site B to Site A before switchback: record counts and checksums match. | ENG | AUTO | |
| 10 | Hand-over Site B Lead to Site A Lead (as step 5). | LEAD | MANUAL | |
| 11 | Node transfers back to Site A. Confirm all eight nodes reporting. | ENG | AUTO | |
| 12 | Site A Lead takes the watch. Log time (UTC). Site B to standby; generator cool-down. | LEAD | MANUAL | |
| 13 | Drill report: times, problems, open items to the maintenance log within 24 h. | LEAD | MANUAL | |

**TARGET: SITE B HOLDS THE WATCH WITHIN 30 MIN OF STEP 1. TIMES RECORDED IN THE WATCH LOG.**

### REVISIONS

| REV | DATE | DESCRIPTION | BY | APPR |
|---|---|---|---|---|
| F | 22 JAN 2024 | Checklist steps automated where possible. | TR | AC |
| E | 09 OCT 2017 | Encrypted links. | | |
| D | 03 MAR 2008 | Replication checks before switchback. | | |
| C | 03 JUN 2002 | Full watch floor at Site B. | | |
| B | 10 APR 2000 | Hand-over timing and phone bridge order revised. | | |
| A | 06 DEC 1999 | Initial issue. | | |

### NOTES

1. Used for the quarterly drill and for any real switchover. Drill dates set by engineering with the watch Leads.
2. Times in UTC. Each step initialled on the printed copy.
3. Steps marked AUTO are run by the switchover checklist tool; the engineer confirms the result.
4. Site B layout per SITE-B-001, power per PWR-002, links per NET-002.
5. If any check fails, stop and stay on the current site; Lead decides whether to continue.

**OER // ENGINEERING**

# SWITCHOVER AND SWITCHBACK PROCEDURE

| DRAWING NO. | REV | SHEET |
|---|---|---|
| SITE-B-002 | F | 1 OF 1 |

| DRAWN | CHECKED | APPROVED |
|---|---|---|
| T. REED | R. KIM | A. COLE |

| DATE | SERIES |
|---|---|
| 22 JAN 2024 | SITES |

CONTROLLED DOCUMENT // CUSTODIAN: ENGINEERING / MAINTENANCE // DO NOT SCALE