Pipetting Protocol

Types of Pipettes – Following Images show the types of Pipettes available in the Lab



Fig 1. 0.5-10 uL Pipette – Eppendorf Brand



Fig 2. 20-200 ul Pipette – Fisherbrand



Fig 3. 100-1000 uL pipette - Thermo

Handling Procedure

First you insert the pipette tip of the definite size.
Sizes available – See the images below



Fig 4. 1000uL Pipette Tip




Fig 5. 200uL Pipette Tip – Useful for 10-100uL, 2-20uL as well as 20-200uL Pipettes



Fig 6 and 7. Pipette tips

2. Setting the parameters – Set the desired volume by rotating the dials



Rotating Dial for Fisherbrand

Fig 8.



Fig 9.




Fig 10.

Note – Rotate the dials slowly so that the spring inside it does not break.

3. Holding the pipette – The image shows the holding position




Fig 11.

Thumb is on the plunger

Rest of the fingers on the sides



Fig 12.



Fig 13. Similarly for left hand using index finger

Note – Evolutionary your index finger has more controlling power than the thumb. So, for less error, it is better to control the plunger with your index finger. You will feel the pressure of the plunger better while pushing.

- 4. Push the plunger until the first stop.
- 5. Pipette out the desired solution.
- 6. Then release it using the second stop by hard pressing the plunger.
- 7. Then rotate the dials to the highest release i.e., for 10 uL the dial should be at 100, for 200 uL the dial should be at 200, and for 1000 uL the dial should be at 1000.