# SXM / TNCM (St. Maarten) (Elev. 14')

- → Engine Failure procedure (Rwy. 10) only. Consider climb to 3000' overwater.
- Customs: No forms required.

#### MIA to SXM – 1

- → Descent- Plan to cross SLUGO @ FL110.
- → Descent (alter. routing)- Plan to cross GOUDA @ FL90'.
- → Request Dir. "AVAKI" for RNAV 10 App.
- Prior to MAP, need HED SEL & Vert Speed!

MIA	126.32	-
u	127.22	-
u	126.27	-
u	132.3	-
SJU r	135.7	-
Juliana App.	128.95	SLUGO

)

### DEPARTURE - E/O 1010'

- → Engine Failure procedure (Rwy. 10) only. Consider climb to 3000' overwater.
- → Expect Bleeds Off Takeoff: AOM, Fast Reference Links, Engine Bleed Off Takeoff.
- → Use caution to not bank too steep. Set bank angle to 30°.
- → At 400', Right to 180 (or assigned heading) & 3000' or 16000' & then expect Dir. JUICE.
- Call Tower 10 min. prior for clearance & when "fully" ready to push & start.
- Approaching US, logon to CPDLC.
- Departure routes this section: **SXM to MIA 1, 2**

#### SXM to MIA – 1

→ Expect revised routing: Dir. JUICE B520 DDP A555 HARDE Y587 AF...

Tower 118.7 Juliana Dep. 128.95 SJU 118.15 / 125.0 135.7

MIA 126.45 HARDE

## SXM to MIA - 2

• See departure notes above.

SDQ	124.3 r	KATOK
PAP	134.15 / 124.5	RETAK
MIA	123.77	ALBBE
MIA	132.3	-

■ ■ ■ <u>A/P INDEX</u> / <u>HOME</u>