Microcomputers I – CE 320

Mohammad Ghamari, Ph.D.

Electrical and Computer Engineering

Kettering University

Announcement

Lecture 20: Subroutines in C

Today's Topics

By the end of this class you should be able to:

- Use multiple files to write a C program
- Share variables and labels between files

- Explain how to pass parameters to C functions
- Explain how to return values from C functions
- Call a subroutine written in assembly from a C program


Introduction

• Up to this point in the course, we mostly have been working with "<u>Absolute Assembly</u>" programs where all code is put into one file, and it is assembled at absolute addresses indicated with "ORG" statements.

• We shall now learn how to put assembly code into two or more "<u>Relocatable Assembly</u>" files which are separately assembled into object (.obj) files and then linked together into an executable file under the control of a "Linker Parameter" (.PRM) file, which tells the linker where to locate the program, data, and stack segments of each relocatable file in the memory space of the microcontroller.

Assembly Process

General case



Introduction...

- The need for separately assembly-language modules, which are separately assembled into object files, and then finally linked together into a single executable file, may not be very apparent in this course, where our applications are relatively short and simple.
- However, in large software development efforts, where several programmers are involved,
 - It is often more convenient for each programmer to develop and maintain their own separate program file which is eventually linked with other programmer's program files into an executable program.
- This approach also shortens compile time, since only the faulty module needs to be recompiled before the files are re-linked.

Using Multiple Files

- To better divide a programming project between programmers, a program is written using several files.
 - One file contains the main program, and it calls subroutines which are contained in the other files.
- During compilation, each separate file is compiled into a separate object file.
 - Recall that an object file contains <u>assembly code</u> and <u>additional information</u>. Among this information are blanks for <u>specific addresses</u>.
 - Consider that assembly (machine) code calls a subroutine by jumping to a <u>specific memory address</u>, not an <u>alphanumeric label</u>.
 - Thus, the specific address must be available in the file with the calling program, not just the assigned label.
 - So, a given project file needs to <u>share the addresses assigned to its labels with the other files</u> for them to complete their call.
 - This sharing and replacing is the **link process**.

Using Multiple Files ...

 A file shouldn't necessarily share all of its labels with all other files. This would require every label in every file to be globally unique.

• For example, the variable "loop" could only be used by one programmer in one file. Everyone else would be prohibited from using it.

 To avoid this, files should be selective in which variable are shared.

Sharing Labels Between Files in Assembly

- To share a label, two things must happen.
 - The file that declares the label must state to the assembler that it will be global, and only one file can do so for a unique label.
 - Any file that wants to use the predefined global label must explicitly ask for it. This process requires three steps.
 - 1. The file that creates the label declares it normally, i.e. by labeling a line in a subroutine, a DS.B statement, etc.
 - 2. The file that creates the label **makes it global** with the **XDEF** assembler directive.
 - 3. All other files that wish to use the label's global value, link to it with an **XREF** directive.

File1.asm

	XDEF	SUB1,TEMP
	ORG	\$1000
TEMP	DS.B	4
	ORG	\$C800
SUB1	CLRA	
	RTS	

File2.asm

	XREF	SUB1		
	ORG	\$2000		
Main	LDS	#\$3600		
	JSR	SUB1	; jumps to \$C800	
	SWI			

File3.asm

	ORG	\$2900	
SUB1	CLRB		
	RTS		
	ORG	\$2100	
	LDS	#\$3600	
	JSR	SUB1	; Jumps to \$2900
	SWI		

File 1 creates the labels and declare them normally by labeling lines in the subroutine.

File 1 creates the labels. So makes them **global** with the **XDEF** assembler directive.

File 2 wishes to use the label's global value, so it links to it with an **XREF** directive.

Functions in C

- A C function may return one value, or "void" if there is no return value.
- The function must be declared in the file that uses it BEFORE any code that calls it. (unlike assembly)
- The function declaration shows the return type and the types of the parameters and order of the parameters. (assembly just had a label)
- The function code looks like the declaration, but parameter labels are included.
- The function itself does not need to be in the same file as the caller.
 - If in the same file, it is typically written after the main program.
- The "return" instruction passes the number specified as the function's output and returns to the calling program.
- If both the <u>calling program</u> and <u>function</u> are written in C and <u>compiled by the same compiler...</u> we don't really care how or where the inputs and output are passed.
- Generally, C compilers do not preserve register values.

Functions in C ...

```
Example:
signed int answer;
signed int myequation(int, int, int);
void main(void)
    signed int my_num = -10;
    answer = myequation(5, my_num, 0x0007);
signed int myequation(int num1, int num2, int num3);
    return num1*num2+num3;
```

- C function is declared before any code calls it.
- · Declaration shows:
 - · Return type
 - Types of parameters
 - · Order of parameters

Main program that calls the function.

- C function: It returns a value.
- The function code looks like the declaration, but parameter labels are included.
- Since the function is written in the same file as the caller, it is located after the main program.

Using Assembly Subroutines in C

- Assembly subroutines are often written in separate files so that inline assembly is not used.
- It is also considered good programming practice <u>not to mix</u> a high-level language and assembly in the same file.
- The basic steps are below, and note that many of the steps deal with the caller and callee being in separate files.
 - 1. Write the subroutine in an assembly file, such as *subfile.asm*. In the assembly, use an **XDEF** directive for the **name of the subroutine**.
 - 2.Write the calling C program in a C file, such as *main.c.*In the C file, use a one line **function declaration** with the same name as the assembly subroutine.

Example

- Some useful assembly subroutines would be conversions.
- Convert a signed char to a signed long.

; assembly file

char s

LDD

CPX

BPL

LDD

XDEF charToLong
ORG \$2800
SEX B,X

#0

#0

endsub

#\$FFFF

 Uses an XDEF directive for the name of the subroutine.

endsub RTS ; D now has signed int

```
// c file
```

long charToLong(signed char);
signed char tinynum;
long longnum;

••••

shortnum = charToLong(tinynum);

 Uses a one line function declaration with the same name as the assembly subroutine.

Parameter Passing Order

Consider the following C subroutine:

```
signed int myequation(int num1, int num2, int num3);
{
    return num1*num2+num3;
}
```

 In many programming languages, subroutine parameters are pushed on the stack by the calling program, and the calling program is also responsible for pulling them off afterwards.

- C Convention: Right to left as they appear in the function declaration.
- Pascal Convention: Left to right as they appear in the function declaration.

Parameter Passing Order ...

- The Freescale's CodeWarrior uses the **Pascal Convention** for subroutines with a fixed number of inputs (which is the only case we'll discuss).
- Also, the last parameter (i.e. the rightmost) is passed by register if the parameter is four bytes or less.
- The result, if there is one, is passed back in register.
- The list below shows which registers are used:

One Byte: B

Two Bytes: D

Three Bytes: B:X

Four Bytes: D:X


Homework Example

Some C subroutines use the returned value to indicate errors.

• Write a subroutine that adds two unsigned integers, generates the answer, and returns 0 for no overflow and 1 for overflow.

• Note, since the subroutine's one return value is used to indicate success or failure, we'll need to return the answer as we did in assembly: pass it by reference as an output.

Homework Example ...



```
; assembly file
         XDEF
                   add_uint
add_uint: TFR
                   D,X
                            ; pointer to sum passed in D
         LDY
                   #0
                            ; assume no overflow
         LDD
                   4,SP
                            ; load first number
         ADDD
                   2,SP
                   skip
         BCC
         LDY
                   #1
skip
         STD
                   0,X
         TFR
                   Y,B
         RTS
// c file that calls subroutine
unsigned int n1 = 5;
unsigned int n2 = 7;
unsigned int answer;
```

```
unsigned int n2 = 7;
unsigned int answer;
...
// exits program if overflow is detected since in C
// 0 means false, anything else means true
if( add_uint(n1, n2, &answer)) return 1;
```