How to apply WISP mode in the AP-router?


Author: Longcent (2006-6-16)

This FAQ is applied to the below Edimax model and operation systems:

- BR-6204Wg / BR-6304Wg.
- Windows 2000/XP.

Introduction:

This FAQ is for guiding you to configure the Edimax AP-Router to connect with the outdoor AP deployed by the WISP for sharing wireless Internet broadband to multiple wired or wireless PCs, as shown in the below figure.



Configuration steps:

1. Set your wire network card to obtain IP automatically.



1.1 Click "Start" in the task bar and select "Control Paned".



1.2 Click "Switch to Classic View" on the left top.



1.3 Double-click the "Network Connection" icon.



1.4 Rick-click the "Local Area Connection" and select "Properties".



1.5 Select "Internet Protocol" and click "Properties".



1.6 Ensure the option "Obtain an IP automatically" and "Obtain DNS address automatically" is checked and click "OK".

2. Edimax Router configuration:




2.1 Enter the default IP of the router.




2.2 Enter the default user name "admin" and password "1234" to log on.


2.3 Click "WAN Type", "Wireless ISP", and "Apply" button.




2.4 Click "Continue" button.




2.5 Click "Site Survey" button.



2.6 Once the "**Site survey**" button is clicked, the pop-up window will show you all the nearbe APs. Please click the name of the AP deployed by your WISP. In this example, we choose "**ISP-2**" and click "**Done**" button.




2.7 Click "Dynamic IP", and "Apply" button.



2.8 Click "**Apply**" button for rebooting the router.



2.9 Check whether the IP addresses assigned by the WISP is logged in the below table by click "Status Info" and "Intenet Connection".



Note:

If these is an IP address shown in the step 2.9 table, it indicates that the router is connected to your ISP, and you are able to access the Internet.

Congratulations!