

#### **Ender-3 Pro 3D Printer**

#### Instructions for assembly


◆ This guide is for the Ender-3 Pro 3D Printer.

 Select the correct input voltage to match your local mains (230V or 115V).

 Because of software/hardware upgrades and model differences, new revisions may not be listed in this guide.

◆ Please plug the Power cord into a three-hole power jack.

Detailed instructions for use are available on the TF card.



Basic Parameters			
Model	Ender-3 Pro	Working Mode	Online or TF card offline
Molding Tech.	FDM	File Format	STL,OBJ,AMF
Printing Size	220*220*250mm	Slice Software	Cura, Repetier-Host ,Simplify3D
Printing Speed	≤180mm/s, Normal 30-60mm/s	Power Supply	Input:AC 100-120V/200-240V 50/60Hz Output:DC 24V
Precision	±0.1mm	Total Power	270W
Slice Thickness	0.1mm-0.4mm	Fliament	1.75mm PLA
Nozzle Diameter	Standard 0.4mm	Operating System	Windows XP/Vista/7/10 MAC、Linux
Nozzle Number	1	Language	中文/English
Nozzle Temp.	≤250°C	Resume Print	YES
Bed Temp.	≤110°C	Filament Detector	NO



#### SHENZHEN CREALITY 3D TECHNOLOGY CO., LTD.

12/F, Block 3, JinChengYuan, Huafan Road, Tongsheng Community, Dalang, Longhua District, Shenzhen, China, 518109 Official Website: www.creality3d.cn

Tel: +86 755-2105 9455

E-mail: info@creality3d.cn cs@creality3d.cn













#### List 1





#### List 2






































# Step 9 \*Don't tighten it too tight Left

