

©2020 Sony Corporation Printed in Japan

3-TAD-034-01(1)

This manual explains how to attach the head and how to adjust the band. For customers using rubber bands, please see the surface. For customers using metal or leather bands, please see reverse side.

Note

Depending on the type of band you are using, accessories and optional parts may differ. Be careful not to accidentally purchase or install the wrong type of accessory.

How to wear the band for more accurate heart

rate measurement

When using the heart rate measurement function, it is recommended that you wear the watch slightly away from your wrist for accurate measurement. As shown in the figure below, wear it about 1 to 3 fingers below the raised part (ÿ) slightly below your wrist (on the elbow side). You may be able to measure more accurately by attaching the device closer to your elbow.




- When measuring your heart rate, wear the watch so that the heart rate sensor is in constant contact with your skin. Accurate measurements may not be possible if the contact of the heart rate sensor is unstable, such as when the band is misaligned. *Be careful not to tighten the band too tightly, as this may lead to poor blood circulation, which may lead to inaccurate measurements or resease.
- •If the band on the heart rate sensor side is too long, the heart rate sensor will easily separate from your skin. Make sure the heart rate sensor is in proper contact with your skin when adjusting the band length.

For details on other heart rate measurement functions, see "About heart rate measurement" in the reference guide.

Precautions when installing the head

The following parts (sold separately) are required to attach the watch head to the wena 3 rubber band. \ddot{y} End piece \ddot{y} End piece connector



wena

ÿ wena 3 rubber body ÿ rubber band

Check the contents



ÿ Charging connector



adjust the length of the band

There are two ways to adjust the length of the band: ÿ 6 mm intervals Cut the bendities bendities by the same field the content of the band in the ban

The rubber band attached to this unit at the time of purchase is the maximum size (3L). Please follow the steps below to adjust the length of the rubber band yourself

1Check your wrist size

The device should be worn on the part slightly away from

the wrist. Wrap the tape measure around one finger's width below (on the elbow side) from the protuberance (ÿ) slightly below the wrist on which the watch is to be worn. For accurate sizing, do not over tighten your arm with the tape measure.



2 Cut the rubber band according to the size

Cut along the cut grooves (6 mm intervals) of the rubber band with scissors. Please refer to the size chart and check the cut position (A-G, a-g) based on your wrist size, then cut along the groove for cutting. Be careful not to cut the four holes on the left and right sides of the wena logo as they are for attaching the base plate.



size char

size wrist size		Cut position	
		left	right
3L	204-209mm		-
LL+	198-203mm	-	а
LL	192-197mm	A.	а
L+	186-191mm	A.	b
L.	180-185mm	В.	b
M+	174-179mm	В.	С
M.	168-173mm	C.	С
S+	162-167mm	C.	d
S.	156-161mm	D.	d
SS+	150-155mm	D.	е
SS	144-149mm	E.	е
3S+	138-143mm	E.	f
3S	132-137mm	F.	f
4S+	126-131mm	F.	g
48	120-125mm	G.	

Note •If

the rubber band is cut short, it can **not** be lengthened. Cut the band **slightly larger than the measured size using the cutting** groove, and adjust the length while actually wearing the band on your arm in step 3 to check it. •If the band is loose, you may not notice the vibration of the notification or keep your heart rate correct

Accurate measurement may not be possible

If you cut the rubber band too much

Rubber bands can be purchased on the wena.jp product page or at some wena dealers. Please check http://wena.jp/for dealers.


3 Attach the rubber band

Attach both ends of the cut rubber band to the band connector

ÿ Insert the spring bar into the outermost spring bar hole of the cut rubber band.



ÿ Align one side of the spring bar passed through the rubber band with the hole inside the band connector. Use the spring bar remover to press the side that matches the hole and the opposite side to the rubber band side and attach it to the hole inside the band connector.




ÿ Pull out the spring bar remover



Please

note that the spring bar is easy to jump. Be careful when handling the spring bar, as it may jump suddenly and cause an injury or accident. The band connector has two mounting holes (A, B). If necessary, change the mounting holes to fine-tune the band length.



If the band is still loose even after making fine adjustments (attaching both sides to B), cut the rubber band at one cut position shorter.

Note

The maximum value for the "wrist size" in the size chart is the size when the spring bar is inserted into the horizontal holes A on both ends of the band connector.

ÿ USB Type-C® cable



ÿ Spring bar (for installation x 2, spare x 2)



ring bar removal



ÿ Start Guide

ÿ Band Guide (this document

ÿ Reference Guide

ÿ Band warranty

attach the head

An end piece and an end piece connector (sold separately) are required to attach the watch head to the watch. For purchase and installation of end pieces and end piece connectors, please check the wena support page. Please check the same page for the recommended watch sizes that wena 3 can be attached to.



http://wena.jp/support.html

Attach end piece to end piece 1 connector

Note:

Since special tools are required, we recommend that you ask a watch repair shop for installation.

Bring the following items to your local watch repair shop to have the end piece installed.


• Target width end piece • End piece connector • Band guide (this document)

To watch repair shops

(1) Insert the C-ring into the end piece connector from the direction shown below.(2) Align the holes of the end piece and the end piece connector.(3) Drive the pin in from the opposite side of the C-ring.


Note :

The end piece connector does not have an arrow pointing to the driving direction like the adjuster.




Attach the end piece to your head 2

While pinching the lever pin of the band, align it with the band attachment hole on the head and release the lever pin.




Attach the base plate to the end piece connector

With the buttons on both ends of the end piece connector pushed in, align the holes in the base plate (ÿ) with the projections on the back of the end piece connector, release the buttons, and attach. At this time, make sure that the base plate does not come off from the end piece connector. Attach the base plate to the other end piece connector in the same way.




Attach the base plate to the rour rubber band

Align your head with the band so that the wena logo on the band is in the center, check the positions of the base plate and the holes in the band, and attach.



The base plate can be attached to the band using the same procedure as "3 Attaching the rubber band" in "Adjusting the length of the band". Attach both baseplates to the band.



The base plate has two holes (A, B) spaced 2.5 mm apart for fine adjustment of the mounting position.

For details on adjusting the band length, refer to the help guide on the wena support page (http://wena.jp/support.html).

Note

- •We do not accept returns or exchanges on the grounds that it cannot be attached to your head. In addition, we are not responsible for any damage caused to the customer in connection with the removal of the wena 3 rubber band model, such as removing the band will void the manufacturer's warranty* of the customer's watch
- Damage caused by breaking the end piece by applying excessive force.

 We are not responsible for any damage.
- •If the rubber band is pulled continuously, it may be suddenly torn off, so attach the base plate in a position where the rubber band has room to spare.
- *For the manufacturer's warranty for your watch, please contact us directly.

 Please contact the manufacturer.

continued on the back

accurately measure your heart rate

Parts marked with can be adjusted.

The end piece supplied with this unit is the wena 3 metal end piece 22

mm (for lug widths of 22 mm or more and less than 23 mm). An end

piece (sold separately) is required to attach a head with a lug width

other than 22 mm or more and less than 23 mm. For purchase and installation of end pieces, please check the wena support page. Please check the same page for the recommended watch sizes that wena 3 can

As shown in the figure below (left), attach the end piece near the 6 o'clock side

of the head and the wena logo on the band. The figure below (right) is attached

lever pin

by pinching the lever pin of the band, aligning it with the hole for band attachment

attach the head

http://wena.jp/support.html

on the head, and releasing the lever pin.

adjust the length of the band

When adjusting the length of the band, there is a risk of damaging small parts or

injuring yourself during work, so we recommend that you have the band adjusted by a watch repair shop. The length of the band at the time of purchase is the maximum size. The length can be adjusted by removing the adjustment piece. If

the band is loose, you may not notice the vibrations and may not be able to

ÿ End piece for wena 3 ÿ


ÿ Adjustable length

Adjustment piece for wena 3

ÿ Band Guide (this manual) ÿ Reference Guide

Bring the following items to your local watch repair shop to have the end ÿ Band warranty

> •Parts required for length adjustment •Band guide (this document)




To watch repair shops

Band length adjustment method

How to remove the adjustment piece and end piece

Only the end piece and the adjustment piece with the mark on the back side of the band can be removed.


Punch out the pin in the direction of (1). After removing the pin and C-ring, Please be careful not to lose it.



How to attach the adjustment piece and end piece

Insert the C-ring in the direction of (1). Align

the holes of the parts with the holes of the parts (2), and drive the pin in from the opposite



If the band on the heart rate sensor side is too long, the heart rate sensor will easily come off the skin. Make sure the heart rate sensor is in proper contact with your skin when adjusting the band length.

•We do not accept returns or exchanges on the grounds that it cannot be attached customer in connection with the removal of the wena 3 metal band model, such as the removal of the band voiding the manufacturer's warranty* of the customer's watch. • Damage caused by breaking the end piece by applying excessive force. We are not responsible for any damage.

*For the manufacturer's warranty for your watch, please contact us directly. Please contact the manufacturer.

Ask a watch repair shop to adjust the length

end piece

CAUTION When adjusting the band, small parts may be damaged or you may be injured during the work, so ask a watch repair shop to hold the band guide (this document). Tell your watch repair shop not to remove the parts (a) that do not have the mark on the back.

end piece

attach the head

mm or more and less than 24 mm). A separately sold leather band is less than 24 mm. For information on purchasing and installing a leather band, please check the wena support page. Please check the same page for the recommended watch sizes that wena 3 can be attached to.



http://wena.jp/support.html

1Attach the spring bar to your head

ÿ Insert the spring bar into one side of the hole in the lug of the head.



 $\ddot{\text{y}}$ lookbethersoprintg their henteover to push in the spring bar and insert the



ÿ Install the spring bar on the other side in the same way.




leather band


Check the contents

ÿ wena 3 leather body ÿ Charging connector



ÿ USB Type-C® cable





ÿ Start Guide

bars (for mounting x 2, spare $_{\rm X}$ 2) $\ddot{\rm y}$ Band guide (this docum ÿ Reference Guide ÿ Band warranty



The leather band that comes with this unit is 22 mm (for a lug width of 22 required to attach a head with a lug width other than 22 mm or more and






note that the spring bar is easy to jump. Be careful when handling the spring bar, as it may jump suddenly and cause an injury or accident.





Attach the leather band to your head 2

Pass the leather hand through the head as shown below so that the wena logo on the band is directly behind the head and can be seen on the outside



•Returns/exchanges due to inability to attach to your head is not acceptable. We are also not responsible for any damages you may incur in connection with putting on or taking off the wena 3 leather model, such as removing the band voids your watch's manufacturer's warranty*.


*For the manufacturer's warranty for your watch, please contact us directly. Please contact the manufacturer.

adjust the length of the band

If the band is loose, you may not notice the vibrations and may not be able to accurately measure your heart rate. Please follow the steps below to adjust the length of the leather band yourself.

Adjust the size of one band

Pass the end of the leather band on the 12 o'clock side through the band connector (ÿ) without the wena logo on the main unit. Secure it by passing the fastener through the hole in the leather band.



Secure the 6 o'clock side through the band connector in the same way




In this state, pass your arm through and adjust the size.

When adjusting the size, remove the leather band from the clasp, change the position of the hole little by little, and fix the clasp through the hole at the

2Attach the leather band

Please attach from the band connector without the wena logo. Pass the tip of the leather band through the band connector from front to back (ÿ). At this time, be careful not to let the slack (ÿ) become too large



Pass the tip of the leather band passed through the back through the loop on the back side of the band connector. Again, be careful not to let the slack (ÿ) become too large



Pass the leather band through the other band connector in the same way.



For details on adjusting the band length, see the help guide on the wena support page (http://wena.jp/support.html).





