

Custom Images and Sounds

By Sanjay and Arvind Seshan


BEGINNER PROGRAMMING LESSON

LESSON OBJECTIVES


1. Learn to use the Display Block and Sound Block to add your custom images and sounds to the EV3

STEP 1: Select Image Editor from the EV3 Menu Note:

The Image Editor can open .rgf, .jpg, .png, and .bmp files. Color images are automatically converted to monochrome images. The .rgf file extension is what LEGO uses.





STEP 2: Open your image




STEP 3: Change its size using the buttons and change the placement by selecting and moving the entire image around








STEP 5: Edit the image, using the tool palette to the left of the editing screen.




STEP 6: Save the image




STEP 7: This image is now ready to use in your display block







ADDING CUSTOM SOUNDS

STEP 1: Select Sound Editor from the Tools Menu



STEP 2: Click on Open and select a sound file or record your own using the red button







ADDING CUSTOM SOUNDS

STEP 3: The sound you selected will appear in the editor


STEP 4: Move the blue bar to change the size of the clip





ADDING CUSTOM SOUNDS

STEP 5: Save the file



STEP 6: The sound will appethe sound block



CREDITS

- This tutorial was created by Sanjay Seshan and Arvind Seshan
- More lessons are available at www.ev3lessons.com



This work is licensed under a <u>Creative Commons Attribution-</u> NonCommercial-ShareAlike 4.0 International License.