


ΣΥΣΤΗΜΑΤΑ ΜΙΚΡΟΥΠΟΛΟΓΙΣΤΩΝ

5Η ΣΕΙΡΑ ΑΣΚΗΣΕΩΝ





JUNE 20, 2021

ΘΟΔΩΡΗΣ ΑΡΑΠΗΣ – EL18028 ΚΡΙΣ ΚΟΥΤΣΗ – EL18905

Ε.Μ.Π. - ΣΧΟΛΗ ΗΛΕΚΤΡΟΛΟΓΩΝ ΜΗΧ. ΚΑΙ ΜΗΧΑΝΙΚΩΝ ΥΠΟΛΟΓΙΣΤΩΝ ΤΟΜΕΑΣ ΤΕΧΝΟΛΟΓΙΑΣ ΠΛΗΡΟΦΟΡΙΚΗΣ ΚΑΙ ΥΠΟΛΟΓΙΣΤΩΝ ΕΡΓΑΣΤΗΡΙΟ ΜΙΚΡΟΫΠΟΛΟΓΙΣΤΩΝ ΚΑΙ ΨΗΦΙΑΚΩΝ ΣΥΣΤΗΜΑΤΩΝ ΑΚΑΛ. ΕΤΟΣ 2020-2021

ΣΥΣΤΗΜΑΤΑ ΜΙΚΡΟΥΠΟΛΟΓΙΣΤΩΝ

```
PRINT MACRO CHAR
PUSH AX
PUSH DX
MOU DL.CHAR
MOU AH.2
INT 21H
POP DX
POP AX
                                                                                                                                   ;MACRO to print a character
                                                                                                                                   ;Char must be defined ;before translation
      ENDM
     DATA_SEG SEGMENT
TABLE DB 128 DUP(?); Initialise TABLE of 128 bytes
LINEFEED DB 13, 10, "$"
DATA_SEG ENDS
    ;Repeat 128 times
;Index of Table
;Store values
MOU DALL MOU
                                                                                                                                    ;Loop 128 times
                                                                                                                                   ; Repeat 64 times, as the number of odd numbers ; Start from 127\,
                                                                                                                                    ;Initialise digit counter
                                                                                                                                   ;Divide number with 10
;Save the rest to the stack
;Increase counter
;If quotient is 0 then there isnt any digit left
                                     DIU BX
PUSH DX
INC CX
CMP AX,0
JNE ADDR2
POP DX
ADD DX,30H
PRINT DL
                                                                                                                                   Read one digit from the stack calculate ASCII code and print the corresponding character on the screen
                                      PRINT DL ; the LOOP ADDR3 PUSH AX PUSH DX MOU AH.09 MOU DX,OFFSET LINEFEED INT 21H POP DX POP AX
      ; b
                                      MOU DI.0
MOU BH.TABLE[DI]
MOU BL.TABLE[DI]
MOU CX.127
                                                                                                                                   ;BH for max, BL for min
                                                                                                                                    ;127 because we start the LOOP from TABLE[1]
      MAX_MIN:
                                      INC DI
CMP BH, TABLE[DI]
JC MAX
CMP TABLE[DI], BL
                                                                                                                                   ; If BH<TABLE[DI] -> CF=1
                                                                                                                                   ; If TABLE[DI] < BL -> CF=1
                                      CMP TABLEIDII, BL
JC MIN
LOOP MAX_MIN
MOU DL, BH
CALL PRINT_8BIT_HEX
PRINT_'_'
     L:
                                        MOU DL, BL
CALL PRINT_8BIT_HEX
JMP QUIT
                                        MOU BH, TABLE[DI]
                                                                                                                                   ;Store new MAX
;Store new MIN
      MAX:
                                       JMP L
MOU BL, TABLE[DI]
JMP L
      MIN:
      QUIT: HLT
MAIN ENDP
```

```
PRINT_8BIT_HEX PROC NEAR

MOU AL,DL
AND DL,OFOH
MOU CL,4
ROR DL,CL
CALL PRINT_HEX
MOU DL,AL
AND DL,OFH
CALL PRINT_HEX
RET
PRINT_BBIT_HEX ENDP

PRINT_HEX PROC NEAR
CMP DL, 9
JG ADDR4
ADD DL, 30H
JMP ADDR5

ADDR4:
ADD DL, 37H
ADDR5:
PRINT_HEX ENDP


CODE_SEG ENDS
END MAIN

PRINT_HEX ENDP

PRINT_HEX ENDP

PRINT_HEX ENDP
```

Παρακάτω φαίνεται η λειτουργία του προγράμματος:



```
PRINT MACRO CHAR
PUSH AX
PUSH DX
                                           ;MACRO to print a character
      MOU DL.CHAR
MOU AH.2
INT 21H
POP DX
POP AX
                                            ;Char must be defined
                                             ;before translation
ENDM
READ MACRO
MOU AH,
INT 21H
                                            ;MACRO to read from keyboard
;The value of ASCII char is returned
;through AL
PRINT_STR MACRO STRING
PUSH DX
PUSH AX
                                          ;MACRO to print string
      MOU DX,
MOU AH,9
INT 21H
POP AX
POP DX
                   OFFSET STRING
ENDM
NEWLINE MACRO LINEFEED ; MACRO to print new line PUSH AX PUSH DX
      MOU AH, 09
MOU DX, OFFSET LINEFEED
INT 21H
POP DX
POP AX
ENDM
DATA_SEG SEGMENT
LINEFEED DB 13, 10, "$"
MSG1 DB 'Z=$'
MSG2 DB ' W=$'
MSG3 DB 'Z+W=$'
MSG4 DB ' Z-W=$'
MSG5 DB ' Z-W=$'
DATA_SEG ENDS
CODE_SEG SEGMENT
ASSUME CS:CODE_SEG, DS:DATA_SEG
MAIN PROC FAR
MOU AX,DATA_SEG
MOU DS,AX
START:
       CALL DEC_KEYB
                                            ;Get tens of Z
      MOU BH, AL
CALL DEC_KEYB
MOU BL, AL
                                             Store tens of Z to BH
                                             Get units of Z
                                            Store units of Z to BL
       CALL DEC_KEYB
                                             Store tens of W to DH
      MOU DH,AL
CALL DEC_KEYB
                                             Get units of W
      MOU DL,AL
PRINT_STR MSG1
PRINT_BH
SUB_BH,30H
PRINT_BL
                                             ;Store units of W to DL
                                            ;Subtract 30 to get the initial number
      PRINT_STR MSG2
PRINT_DH
SUB_DH,30H
PRINT_DL
       SUB DL, 30H
```

```
;(2)
       NEWLINE LINEFEED
      NEWLINE LINEFEED
MOU AL,10
MUL BH
ADD BL,AL
MOU AL,10
MUL DH
ADD DL,AL
MOU AL,DL
PUSH AX
ADD DL,BL
PRINT_STR MSG3
CALL PRINT_8BIT_HEX
POP AX
                                             ;Multiply tens of Z with 10 to
                                             store the whole number in BL
                                             ;Same with W in DL
                                             ;Save W in AL
;Push AL because it will change
;Store Z+W in DL
CALL PRINT_8BIT_HEX
POP AX
CMP BL,AL
JC NEGATIVE
SUB BL,AL
MOU DL,BL
PRINT_STR MSG4
CALL PRINT_8BIT_HEX
NEWLINE LINEFEED
NEWLINE LINEFEED
JMP START
NEGATIVE:
SUB AL,BL
                                             ;Retrieve W
                                             ;If Z < W then jump to NEGATIVE
                                             ;Else store Z-W in BL
                                             ; and move it to DL to print it
                                             ;Get new data
       SUB AL,BL
MOU DL,AL
PRINT_STR MSG5
CALL PRINT_8BIT_HEX
NEWLINE LINEFEED
NEWLINE LINEFEED
JMP START
                                             ;Store W-Z in AL to get the absolute value ; and move it to DL to print it
                                             ;Get new data
MAIN ENDP
PRINT_8BIT_HEX PROC NEAR
MOU AL, DL
AND DL, OFOH
MOU CL, 4
ROR DL, CL
                                            ;Print 8bit number in hex
                                             ;Isolate 4 MSB
            CALL PRINT_HEX
MOU DL.AL
AND DL.OFH
                                             ;Isolate 4 LSB
            CALL PRINT_HEX
PRINT_8BIT_HEX ENDP
PRINT_HEX PROC NEAR CMP DL. 9
                                             ; If number is between 0 and 9 add 30H
            JG ADDŔ4
            ADD DL, 3
JMP ADDR5
                          30H
ADDR4:
            ADD DL, 37H
                                             ;Else add 37H
ADDR5:
            PRINT DL
                                             ;Print character
            RET
DEC_KEYB PROC NEAR
I GNORE:
       READ
                                             Read char from keyboard
       CMP AL, 30H
JL IGNORE
CMP AL, 39H
                                             ;Check if char is decimal digit
;If it isn't then wait for a valid input
                    30H
       JG I GNORE
       RE
DEC_KEYB ENDP
CODE_SEG ENDS
END MAIN
```

Παρακάτω φαίνεται η λειτουργία του προγράμματος:



```
PRINT MACRO CHAR
                                               ;MACRO to print a character
       PUSH AX
PUSH DX
       MOU DL,CHAR
MOU AH,2
INT 21H
POP DX
POP AX
                                                ;Char must be defined
                                                ;before translation
ENDM
MOU AH, 8
INT 21H
ENDM
                                                ;MACRO to read from keyboard
                                                ;The value of ASCII char is returned ;through AL
NEWLINE MACRO LINEFEED
PUSH AX
PUSH DX
                                           ;MACRO to print new line
       MOU AH.09
MOU DX.OFFSET LINEFEED
INT 21H
POP DX
POP AX
DATA_SEG SEGMENT
LINEFEED DB 13, 10, "$"
DATA_SEG ENDS
CODE_SEG SEGMENT
ASSUME CS:CODE_SEG, DS:DATA_SEG
MAIN PROC FAR
MOU AX, DATA_SEG
MOU DS, AX
START:

MOU BX,0

CALL HEX_KEYB

CMP AL, 'T'

JE QUIT

MOU BH,AL

CALL HEX_KEYB


CMP AL, 'T'

JE QUIT

MOU BL,AL
                                                ;Get first hex digit
;If it's T then end
                                                ;Else store its value to BH
                                                ;BX will have the 12 bit number ;Get second hex digit
       JE QUIT
MOU BL, AL
MOU CL, 4
ROL BL, CL
CALL HEX_KEYB
CMP AL, T'
JE QUIT
ADD BL, AL
MOU AX, BX
MOU CX, 0
CALL PRINT_DEC
PRINT '='
CALL PRINT_BIN
PRINT '='
CALL PRINT_OCT
                                                ;Store its value to BL
                                                ;Rotate the value to 4 MSB
                                                ;Get third hex digit
                                                ;BL has the 2nd and 3rd digit
       CALL PRINT_OCT
NEWLINE LINEFEED
JMP START
QUIT:
       HLT
MAIN ENDP
```

```
PRINT_OCT PROC NEAR
PUSH AX
MOU BX,8
MOU CX,0
GETOCT:
                                            ;Print 12bit number in octal
                                             ;We have to divide number with 8 ;Initialise counter
       MOU DX,0
DIU BX
PUSH DX
INC CL
CMP AX,0
JNE GETOCT
                                             ;DX will have the remainder of the division
                                             ;Divide number with 8
;Save the remainder to the stack
;Increase counter
                                             ; If quotient is 0 then there isnt any digit left
PRINTOCT:
       POP AX
ADD AL,48
                                            ;Read one digit from the stack
;Calculate ASCII code and print the
       PRINT AL
LOOP PRINTOCT
                                             corresponding character on the screen
       POP AX
PRINT_OCT ENDP
PRINT_BIN PROC NEAR
                                            ;Print 12bit number in binary
       PUSH AX
MOV BX,2
MOV CX,0
                                            ;We have to divide number with 2;We follow the same process as above;but instead of dividing by 8;we divide number with 2
GETBIN:
      BIN:
MOU DX,0
DIU BX
PUSH DX
INC CL
CMP AX,0
JNE GETBIN
PRINTBIN:
       POP AX
ADD AL,48
PRINT AL
                                             ;Calculate ASCII code and print the
                                             corresponding character on the screen
               PRINTBIN
       POP AX
       RET
PRINT_BIN ENDP
PRINT_DEC PROC NEAR
                                            ;Print 12bit number in decimal
       PUSH AX
MOU BX,10
MOU CX,0
                                             ;We have to divide number with 10
                                             ;We follow the same process as above ;but instead of dividing by 2 ;we divide number with 10
GETDEC:
MOU DX.0
DIU BX
PUSH DX
INC CX
CMP AX.0
JNE GETDEC
PRINTDEC:
       POP DX
ADD DX,48
                                             ;Calculate ASCII code and print
       PRINT DL
                                             the corresponding character on the screen
       POP AX
PRINT_DEC ENDP
                                             ; Read a hex digit from the keyboard ; and store it in {\tt AL}
HEX_KEYB PROC NEAR
I GNORE:
       READ
                                             ;Read from keyboard
;If char is T then end routine
       READ
CMP AL, 'T'
JE ADDR2
CMP AL, 30H
JL IGNORE
CMP AL, 39H
JG ADDR1
SUB AL, 30H
JMP ADDR2
                                             ;Check if char is a digit
                                            ;If it isn't then wait for a valid input
;Check if char is a digit greater than 9
;If it is then check if its A,B,C,D,E or F
;Export the correct number from its ASCII value
ADDR1:
                                             ;Check if char is a valid hex digit;If it isn't then wait for a valid input
       JL IGNORE
CMP AL, F'
JG IGNORE
SUB AL, 37H
                                            ;Export the correct number from its ASCII value
ADDR2:
RET
HEX_KEYB ENDP
CODE_SEG ENDS
END MAIN
```

Παρακάτω φαίνεται η λειτουργία του προγράμματος για εισόδους ABC, 123, 443 αντίστοιχα. Επιλέξαμε να μην εκτιπώνουμε την είσοδο (που είναι σε δεκαεξαδική μορφή) επειδή δεν διευκρινιζόταν στην εκφώνηση. Αν θέλαμε να το εκτυπώσουμε απλά θα κάναμε print τους χαρακτήρες που εισάγουμε και στην συνέχεια ένα "=".




```
PRINT MACRO CHAR
PUSH AX
PUSH DX
                                                       ;MACRO to print a character
        MOU DL, CHAR
MOU AH, 2
INT 21H
POP DX
POP AX
                                                        ;Char must be defined
                                                         ;before translation
ENDM
                                                        ;MACRO to read from keyboard
;The value of ASCII char is returned
;through AL
READ MACRO
      MOU AH,
INT 21H
NEWLINE MACRO LINEFEED ; MACRO to print new line PUSH AX PUSH DX
        MOU AH, 09
MOU DX, OFFSET LINEFEED
INT 21H
POP DX
POP AX
DATA_SEG SEGMENT
LINEFEED DB 13, 10, "$"
TABLE DB 20 DUP(?) ;7
                                                     ;Table to store the characters from keyboard
DATA_SEG ENDS
CODE_SEG SEGMENT
ASSUME_CD:CODE_SEG, DS:DATA_SEG
MAIN PROC FAR
MOU AX, DATA_SEG
MOU DS, AX
START:
MOU DI,0
MOU CL,0
GETCHAR:
                                                        ;Initialise table pointer
                                                        ;Initialise counter
                                                        ;Read from keyboard
;If we typed '=' then end
        READ
        READ
CMP AL,61
JE QUIT
CMP AL,13
JE PRINT_ANS
CMP AL,48
JB GETCHAR
CMP AL,122
JA GETCHAR
CMP AL,57
JBE SAUECHAR
CMP AL,97
                                                        ;If we pressed enter then go
;go to printing process
;ASCII values less than 48 don't
;have a value that we want
;ASCII values greater than 122 don't
;have a value that we want
;If ASCII value is between 48 and 57 then
;char is a number, so store it in the tab
                                                       ;char is a number, so store it in the table
;If ASCII value is between 58 and 96 then
         CMP AL,97
JB GETCHAR
                                                        ;we don't have a value that we want;Else the value is between 97 and 122, so;char is a case letter of the alphabet
```

```
SAUECHAR:
      PRINT AL
     MOU TABLE[DI], AL
INC DI
INC CL
MOU DL, CL
CMP CL, 20
JB GETCHAR
                                        ;Store char in table
                                        ; Increase table pointer
                                        ;Increase counter
                                       ;DL will be used to restore CL's value ;Check if we typed 20 characters ;If not then read next char
PRINT_ANS:
NEWLINE_LINEFEED
      MOU DI,0
                                        ;Initialise table pointer
GETCAP:
     MOU AL, TABLE[DI]
CMP AL, 97
JB NEXTCAP
CMP AL, 122
JA NEXTCAP
SUB AL, 32
                                        ;Getting case letters from the
                                        table and making them capital
                                        ;Subtracting 32 makes this transformation
      PRINT AL
                                        ;Print capital letter
NEXTCAP:
      INC DI
LOOP GETCAP
PRINT '-'
                                        ;Increase pointer
MOU CL, DL
MOU DI, Ø
GETNUM:
                                        ;Restoring CL's value because
                                        ;it's needed in GETNUM's loop
     MOU AL, TABLE[DI]
CMP AL, 48
JB NEXTNUM
                                        ;Getting all numbers from
                                        ;table and printing them
      CMP AL,57
JA NEXÍNUM
PRINT AL
NEXTNUM:
     INC DI
LOOP GETNUM
NEWLINE LINEFEED
NEWLINE LINEFEED
      JMP START
QUIT:
HLT
MAIN ENDP
CODE_SEG ENDS END MAIN
```

Παρακάτω φαίνεται η λειτουργία του προγράμματος, αρχικά με 20 χαρακτήρες (χωρις να πατήσουμε ENTER), και στις υπόλοιπες 3 εισόδους πατώντας ENTER.





Το πρόγραμμα προσομοιώνει ένα σύστημα λήψης θερμοκρασίας που περιλαμβάνει έναν αισθητήρα θερμοκρασίας, έναν μετατροπέα από αναλογική τιμή σε ψηφιακή (ADC) και έναν υπολογιστή με τον μΕ 80x86. Υποτίθεται ότι ο αισθητήρας μετρά τη θερμοκρασία και παρέχει μία τάση στο διάστημα [0,3] Volts στον ADC. Ο ADC ψηφιοποιεί την τάση του αισθητήρα στο διάστημα [0,4095] Volts. Η ψηφιοποιημένη τάση παρέχεται ως είσοδος στον υπολογιστή, ο οποίος λαμβάνει τη θερμοκρασία μέσω μιας 16-bit θύρας εισόδου σε δυαδική μορφή των 12 bits και την απεικονίζει ως έξοδο στην οθόνη με έναν 4ψήφιο δεκαδικό αριθμό με ένα κλασματικό ψηφίο (XXXX,X) από 0,0 έως 1200,0 °C. Το σύστημα περιγράφεται από το παρακάτω σχήμα.

Η θύρα εισόδου προσομοιώνεται από το πληκτρολόγιο, μέσω του οποίου εισάγονται τα δεδομένα (η τάση του ADC) ως 3 δεκαεξαδικά ψηφία. Με την εκκίνηση της εκτέλεσης του προγράμματος εμφανίζεται το μήνυμα START(Y,N): και ο χρήστης επιλέγει αν αυτό θα λειτουργήσει (Υ) ή θα τερματιστεί (Ν). Σε περίπτωση λειτουργίας, το πρόγραμμα δέχεται τα 3 ψηφία της εισόδου (μόνο έγκυρα) και εμφανίζει τη θερμοκρασία. Το πρόγραμμα είναι συνεχούς λειτουργίας, τερματίζεται οποιαδήποτε στιγμή αν δοθεί ο χαρακτήρας Ν και σε περίπτωση θερμοκρασίας μεγαλύτερης από 1200,0 °C εμφανίζει το μήνυμα σφάλματος ERROR. Το πρόγραμμα αρχικά εμφανίζει το μήνυμα εκκίνησης (STARTPROMPT) και τον χαρακτήρα που δίνει ο χρήστης. Κατά τη λειτουργία του, δέχεται τα 3 ψηφία της εισόδου στον AL με κλήση της ρουτίνας HEX ΚΕΥΒ και τα ενώνει στον DX ολισθαίνοντάς τα κατάλληλα. Στη συνέχεια συγκρίνει την είσοδο με τα ψηφιοποιημένα άνω όρια των κλάδων της χαρακτηριστικής καμπύλης του αισθητήρα για να αποφασίσει σε ποιον κλάδο ανήκει και υπολογίζει τη θερμοκρασία υλοποιώντας την αντίστοιχη συνάρτηση. Για την υλοποίηση προγραμματιστικά των συναρτήσεων χρησιμοποιήθηκε η εντολή DIV που δίνει πηλίκο, άρα τα αποτελέσματα των υλοποιήσεων αυτών είναι τα ακέραια μέρη των ζητούμενων αριθμών και αποθηκεύονται στον ΑΧ. Από το υπόλοιπο της διαίρεσης, που αρχικά τοποθετείται στον DX, προκύπτει το μονοψήφιο κλασματικό μέρος των αριθμών. Οι συναρτήσεις των 2 κλάδων και ο τρόπος υπολογισμού των κλασματικών μερών φαίνονται παρακάτω.

όπου Τ η ζητούμενη θερμοκρασία και V η τάση εξόδου του ADC. Επισημαίνεται ότι το κλασματικό μέρος είναι ίδιο και για τους 2 κλάδους, αφού έχουν τον ίδιο διαιρέτη στη συνάρτησή τους. Επισημαίνεται ακόμη ότι οι παραπάνω διαιρέσεις αναφέρονται σε ακέραια διαίρεση και ότι τα ψηφιοποιημένα άνω όρια των κλάδων της χαρακτηριστικής καμπύλης του αισθητήρα είναι οι τιμές της τάσης εξόδου του ADC για τις οποίες παίρνουμε θερμοκρασία όχι μεγαλύτερη από τις αντίστοιχες τιμές του οριζόντιου άξονα που φαίνονται στο σχήμα (άρα για τον 1ο κλάδο το 2 μετατρέπεται σε 2047 και για τον 2ο το 3 σε 3071). Η εμφάνιση του ακέραιου μέρους γίνεται μέσω του ΑΧ με κλήση της ρουτίνας PRINT_DEC16 που τυπώνει έναν 16-bit δεκαδικό αριθμό και ακολουθείται από την εμφάνιση του κλασματικού μέρους.

```
PRINT_STR MACRO STRING
                                         ;MACRO to print string
      PUSH DX
PUSH AX
      MOU DX, MOU AH, 9
INT 21H
POP AX
POP DX
                  OFFSET STRING
ENDM
                                         ;MACRO to read from keyboard
;The value of ASCII char is returned
READ MACRO
      MOU AH,
INT 21H
                                         ;through AL
ENDM
PRINT MACRO CHAR
PUSH AX
PUSH DX
                                      ;MACRO to print a character
     MOU DL CHAR
MOU AH, 2
INT 21H
POP DX
POP AX
                                       ;Char must be defined
                                       ;before translation
NEWLINE MACRO LINEFEED
                                     ;MACRO to print new line
     PUSH AX
PUSH DX
     MOU AH, 09
MOU DX, OFFSET LINEFEED
INT 21H
POP DX
POP AX
ENDM
     LINEFEED DB 13, 10, "$"
STARTPROMPT DB "START(Y,N):$"
ERRORMSG DB "ERROR$"
                                                      ;Starting message
CODE SEGMENT
     ASSUME CS:CODE, DS:DATA
MAIN PROC FAR
MOU AX, DATA
MOU DS, AX
     PRINT_STR STARTPROMPT
```

```
START:
                                             ;Wait until Y or N is typed
       READ
       CMP AL,'N'
JE QUIT
CMP AL,'Y'
JE CONT
JMP START
                                             ; If we typed N ; then end
                                             ; If we typed Y
                                             ;then go to main process
PRINT AL
NEWLINE LINEFEED
NEWLINE LINEFEED
                                             ;Print Y
MOU DX.0
MOU CX.3
                                             ;Initialise for 3 hex digits
READTEMP:
                                             Input
       TE GOIT
CWL TEX KEAR
                                             Read input from keyboard
       PUSH CX
DEC CL
ROL CL,2
MOU AH,0
ROL AX,CL
OR DX,AX
POP CX
LOOP READTEMP
PRINT ''
MOU AX DX
                                             ;DX will have the 12bit input
                                             ;Rotate left 8, 4, 0 digits
                                             ;Add digit to reg
       MOU AX,DX
CMP AX,2047
JBE BRANCH1
CMP AX,3071
JBE BRANCH2
                                             ;U<=2 ?
                                             ;U<=3 ?
       PRINT_STR ERRORMSG
NEWLINE LINEFEED
                                             ; U > 3
        JMP NEWTEMP
BRANCH1:
                                             ;1st branch: U<=2, T=(800*U) div 4095
MOU BX,800
MUL BX
MOU BX,4095
DIU BX
JMP SHOWTEMP
BRANCH2:
                                             ;2nd branch: 2\langle U \langle =3, T = ((3200 \times U)) \text{ div } 4095 \rangle -1200
BRANCH2:
MOU BX,3200
MUL BX
MOU BX,4095
DIU BX
SUB AX,1200
SHOWTEMP:
       CALL PRINT_DEC16
                                             ;Show integet
                                             ;Fractional part = (remainder*10) div 4095
       MOV AX,DX
MOV BX,10
MUL BX
MOV BX,4095
DIV BX
PRINT ','
ADD AL,48
PRINT AL
NEWLINE LINEFEED
JWP NEWTEMP
                                                                 ı
                                             ;Calculate ASCII code and print
                                             fractional part on the screen
QUIT:
       PRINT AL
HLT
MAIN ENDP
```

```
HEX_KEYB PROC NEAR
                                       ;Routine to get hex values from keyboard
READ1:
      READ
     CMP AL,'N'
JE RETURN
CMP AL,48
JL READ1
CMP AL,57
JG LETTER
                                       ;If ASCII value is between 48 ;and 57 then char is a number
PRINT AL
SUB AL,48
JMP RETURN
LETTER:
CMP AL,'A'
                                       Remove ASCII code to get the correct number
                                       ;A...F
;<A ?
      CMP HL, H
JL READ1
CMP AL, 'F'
JG READ1
PRINT AL
                                       ;>F ?
      SUB AL,55
                                       ;ASCII code
RETURN:
HEX_KEYB ENDP
PRINT_DEC16 PROC NEAR
PUSH DX
MOV BX,10
MOV CX,0
                                       ;Routine to print fractional number
                                       ;We have to divide number with 10 ;Initialise counter
GETDEC:
     MOU DX,0
DIU BX
PUSH DX
INC CL
CMP AX,0
JNE GETDEC
                                       ;DX will have the remainder of the division
                                       ;Divide number with 10
                                       ;Save the remainder to the stack
                                       ;Increase counter
                                       ; If quotient is 0 then there isnt any digit left
PRINTDEC:
      POP DX
ADD DL,48
                                       Read one digit from the stack ;Calculate ASCII code and print the
      PRINT DL
LOOP PRINTDEC
                                       corresponding character on the screen
      POP DX
PRINT_DEC16 ENDP
CODE ENDS
END MAIN
```

Παρακάτω φαίνεται η λειτουργία του προγράμματος (με είσοδο Ν τερματίζει):

