


### BİL 218-BİLGİSAYAR ORGANİZASYONU

Dr. Öğr. Üyesi İclal Çetin Taş

# Computer Organization and Architecture

Designing for Performance



Chapter 2

Performance Concepts

# Designing for Performance

The cost of computer systems continues to drop dramatically, while the performance and capacity of those systems continue to rise equally dramatically

Today's laptops have the computing power of an IBM mainframe from 10 or 15 years ago

Processors are so inexpensive that we now have microprocessors we throw away

Desktop applications that require the great power of today's microprocessor-based systems include:

- Image processing
- Three-dimensional rendering
- Speech recognition
- Videoconferencing
- Multimedia authoring
- Voice and video annotation of files
- Simulation modeling
- Businesses are relying on increasingly powerful servers to handle transaction and database processing and to support massive client/server networks that have replaced the huge mainframe computer centers of yesteryear
- Cloud service providers use massive high-performance banks of servers to satisfy high-volume,
   high-transaction-rate applications for a broad spectrum of clients

## Performance

#### 1. Designing for Performance (Performans İçin Tasarım)

Performans, mikroişlemcilerin tasarımında en kritik faktörlerden biridir. Mikroişlemci tasarımı, işlemci hızının artırılması, enerji verimliliği ve işlem birimlerinin etkinliğini en üst düzeye çıkaracak şekilde yapılmalıdır. Bu, işlemcinin işlem gücünü (clock speed), çekirdek sayısını, veri yollarını, bellek hiyerarşisini ve daha fazlasını optimize etmeyi içerir. Performans odaklı tasarım, genellikle belirli bir görevde (örneğin, oyunlar, video işleme veya hesaplamalı bilimler) yüksek verimlilik sağlamak için yapılır.

#### 2. Microprocessor Speed (Mikroişlemci Hızı)

Mikroişlemci hızı, genellikle saat frekansı (clock speed) ile ölçülür ve genellikle gigahertz (GHz) cinsinden ifade edilir. Ancak hız tek başına yeterli değildir. Hız, işlemcinin bir döngüde ne kadar işlem gerçekleştirebileceğini belirler, ancak bu hızın etkinliği, bellek erişimi, veri yolu genişliği ve paralel işleme yetenekleri gibi faktörlerle de ilgilidir. Hız arttıkça, işlemcinin enerji tüketimi ve ısınma problemleri de artabilir. Bu yüzden hız, enerji verimliliği ve ısınma ile dengelenmelidir.

## Performance

#### 3. Performance Balance (Performans Dengesi)

Performans dengesi, mikroişlemci tasarımında önemli bir faktördür. Bu denge, hız, enerji verimliliği, paralellik, bellek erişim süreleri ve işlem birimlerinin etkinliği gibi farklı faktörlerin optimize edilmesiyle sağlanır. Örneğin, bir işlemcinin hızını artırmak, enerji tüketiminin artmasına yol açabilir, bu da sistemin verimliliğini olumsuz etkileyebilir. Bu yüzden, mikroişlemcilerde performans, güç tüketimi, ısı dağılımı ve güvenilirlik arasında iyi bir denge kurmak önemlidir.

## Performance

### 4. Improvements in Chip Organization and Architecture (Yonga Organizasyonu ve Mimarisindeki İyileştirmeler)

Mikroişlemci mimarisi, işlemcinin genel tasarımını ve iç yapılarını tanımlar. Bu, işlemcinin çekirdek sayısı, her çekirdeğin işleyebileceği veri miktarı, işlem birimlerinin organizasyonu ve daha fazlasını içerir. Mimariyi iyileştirmek, işlemcinin verimliliğini artırabilir. Örneğin:

**Çok çekirdekli mimariler**: Bir işlemci birden fazla çekirdeğe sahip olduğunda, paralel işlem yapabilme kapasitesine sahip olur ve böylece birden fazla görevi aynı anda gerçekleştirebilir.

Pipelining: Veri işleme sürecinde adımların paralel hale getirilmesi, işlemci hızını artırabilir.


**Out-of-order execution**: Komutların sırasının, bağımsız komutlar arasında dinamik olarak yeniden düzenlenmesi, işlemcinin daha verimli çalışmasını sağlar.

Cache ve bellek hiyerarşisi: Veriye hızlı erişim için cache'lerin (önbelleklerin) etkin kullanımı da işlemcinin hızını ve performansını artırır.

# Microprocessor Speed

Techniques built into contemporary processors include:

Pipelining	Processor moves data or instructions into a conceptual pipe with all stages of the pipe processing simultaneously
Branch prediction	Processor looks ahead in the instruction code fetched from memory and predicts which branches, or groups of instructions, are likely to be processed next
Superscalar execution	This is the ability to issue more than one instruction in every processor clock cycle. (In effect, multiple parallel pipelines are used.)
Data flow analysis	Processor analyzes which instructions are dependent on each other's results, or data, to create an optimized schedule of instructions
Speculative execution	Using branch prediction and data flow analysis, some processors speculatively execute instructions ahead of their actual appearance in the program execution, holding the results in temporary locations, keeping execution engines as busy as possible






Figure: Superscalar Organization (Source: (Stallings, 2015))




Figure: Comparison of superscalar and superpipeline approaches (Source:

Performance Balance

 Adjust the organization and architecture to compensate for the mismatch among the capabilities of the various components

Architectural examples include:

Increase the number
of bits that are
retrieved at one time
by making DRAMs
"wider" rather than
"deeper" and by
using wide bus data
paths

Reduce the frequency
of memory access by
incorporating
increasingly complex
and efficient cache
structures between
the processor and
main memory

Change the DRAM
interface to make it
more efficient by
including a cache or
other buffering
scheme on the DRAM
chip

Increase the interconnect bandwidth between processors and memory by using higher speed buses and a hierarchy of buses to buffer and structure data flow




Figure 2.1 Typical I/O Device Data Rates

# Improvements in Chip Organization and Architecture

#### Increase hardware speed of processor

- Fundamentally due to shrinking logic gate size
  - More gates, packed more tightly, increasing clock rate
  - Propagation time for signals reduced

#### Increase size and speed of caches

- Dedicating part of processor chip
  - Cache access times drop significantly

#### Change processor organization and architecture

- Increase effective speed of instruction execution
- Parallelism

# Problems with Clock Speed and Logic Density

#### Power

- Power density increases with density of logic and clock speed
- Dissipating heat

#### RC delay

- Speed at which electrons flow limited by resistance and capacitance of metal wires connecting them
- Delay increases as the RC product increases
- As components on the chip decrease in size, the wire interconnects become thinner, increasing resistance
- Also, the wires are closer together, increasing capacitance

#### Memory latency and throughput

 Memory access speed (latency) and transfer speed (throughput) lag processor speeds





Figure 2.2 Processor Trends



# Many Integrated Core (MIC) Graphics Processing Unit (GPU)

#### MIC

- Leap in performance as well as the challenges in developing software to exploit such a large number of cores
- The multicore and MIC strategy involves a homogeneous collection of general purpose processors on a single chip

#### **GPU**

- Core designed to perform parallel operations on graphics data
- Traditionally found on a plug-in graphics card, it is used to encode and render 2D and 3D graphics as well as process video
- Used as vector processors for a variety of applications that require repetitive computations

## Amdahl's Law

#### Gene Amdahl

Deals with the potential speedup of a program using multiple processors compared to a single processor

Illustrates the problems facing industry in the development of multicore machines

 Software must be adapted to a highly parallel execution environment to exploit the power of parallel processing

Can be generalized to evaluate and design technical improvement in a computer system




Figure 2.3 Illustration of Amdahl's Law




Figure 2.4 Amdahl's Law for Multiprocessors

## Little's Law

Fundamental and simple relation with broad applications

Can be applied to almost any system that is statistically in steady state, and in which there is no leakage

#### Queuing system

- If server is idle an item is served immediately, otherwise an arriving item joins a queue
- There can be a single queue for a single server or for multiple servers, or multiple queues with one being for each of multiple servers

Average number of items in a queuing system equals the average rate at which items arrive multiplied by the time that an item spends in the system

- Relationship requires very few assumptions
- Because of its simplicity and generality it is extremely useful




Figure 2.5 System Clock


#### Table 2.1 Performance Factors and System Attributes

	lc	р	m	k	τ
Instruction set architecture	Х	Х			
Compiler technology	X	Х	Х		
Processor implementation		Х			Х
Cache and memory hierarchy				Х	Х

$$CPI = \frac{\sum_{i=1}^{n} (CPI_i \times I_i)}{I_c} \qquad T = I_c \times CPI \times \tau$$

$$T = I_c \times [p + (m \times k)] \times \tau$$

# Calculating the Mean



The three common formulas used for calculating a mean are:

- Arithmetic
- Geometric
- Harmonic




Figure 2.6 Comparison of Means on Various Data Sets

(each set has a maximum data point value of 11)

### Arithmetic Mean

- An Arithmetic Mean (AM) is an appropriate measure if the sum of all the measurements is a meaningful and interesting value
- The AM is a good candidate for comparing the execution time performance of several systems

For example, suppose we were interested in using a system for large-scale simulation studies and wanted to evaluate several alternative products. On each system we could run the simulation multiple times with different input values for each run, and then take the average execution time across all runs. The use of multiple runs with different inputs should ensure that the results are not heavily biased by some unusual feature of a given input set. The AM of all the runs is a good measure of the system's performance on simulations, and a good number to use for system comparison.

- The AM used for a time-based variable, such as program execution time, has the important property that it is directly proportional to the total time
- If the total time doubles, the mean value doubles

Table 2.2 A Comparison of Arithmetic and Harmonic Means for Rates

	Computer A time (secs)	Computer B time (secs)	Computer C time (secs)	Computer A rate (MFLOPS)	Computer B rate (MFLOPS)	Computer C rate (MFLOPS)
Program 1 (10 <sup>8</sup> FP ops)	2.0	1.0	0.75	50	100	133.33
Program 1 (10 <sup>8</sup> FP ops)	0.75	2.0	4.0	133.33	50	25
Total execution time	2.75	3.0	4.75	-	-	-
Arithmetic mean of times	1.38	1.5	2.38	-	-	-
Inverse of total execution time (1/sec)	0.36	0.33	0.21	-	-	-
Arithmetic mean of rates	-	-	-	91.67	75.00	79.17
Harmonic mean of rates	-	-	-	72.72	66.67	42.11

Table 2.3
A Comparison of Arithmetic and Geometric Means for Normalized Results

(a) Results normalized to Computer A

	Computer A time	Computer B time	Computer C time
Program 1	2.0 (1.0)	1.0 (0.5)	0.75 (0.38)
Program 2	0.75 (1.0)	2.0 (2.67)	4.0 (5.33)
Total execution time	2.75	3.0	4.75
Arithmetic mean of normalized times	1.00	1.58	2.85
Geometric mean of normalized times	1.00	1.15	1.41

#### (a) Results normalized to Computer B

	Computer A time	Computer B time	Computer C time
Program 1	2.0 (2.0)	1.0 (1.0)	0.75 (0.75)
Program 2	0.75 (0.38)	2.0 (1.0)	4.0 (2.0)
Total execution time	2.75	3.0	4.75
Arithmetic mean of normalized times	1.19	1.00	1.38
Geometric mean of normalized times	0.87	1.00	1.22

Table 2.4
Another Comparison of Arithmetic and Geometric Means for Normalized Results

(a) Results normalized to Computer A

	Computer A time	Computer B time	Computer C time
Program 1	2.0 (1.0)	1.0 (0.5)	0.20 (0.1)
Program 2	0.4 (1.0)	2.0 (5.0)	4.0 (10.0)
Total execution time	2.4	3.00	4.2
Arithmetic mean of normalized times	1.00	2.75	5.05
Geometric mean of normalized times	1.00	1.58	1.00

#### (a) Results normalized to Computer B

	Computer A time	Computer B time	Computer C time
Program 1	2.0 (2.0)	1.0 (1.0)	0.20 (0.2)
Program 2	0.4 (0.2)	2.0 (1.0)	4.0 (2.0)
Total execution time	2.4	3.0	4.2
Arithmetic mean of normalized times	1.10	1.00	1.10
Geometric mean of normalized times	0.63	1.00	0.63

## Benchmark Principles

Desirable characteristics of a benchmark program:

- 1. It is written in a high-level language, making it portable across different machines
- 2. It is representative of a particular kind of programming domain or paradigm, such as systems programming, numerical programming, or commercial programming
- 3. It can be measured easily
- 4. It has wide distribution

# System Performance Evaluation Corporation (SPEC)

#### Benchmark suite

- A collection of programs, defined in a high-level language
- Together attempt to provide a representative test of a computer in a particular application or system programming area

#### SPEC

- An industry consortium
- Defines and maintains the best known collection of benchmark suites aimed at evaluating computer systems
- Performance measurements are widely used for comparison and research purposes

### SPEC CPU2017

Best known SPEC benchmark suite

Industry standard suite for processor intensive applications

Appropriate for measuring performance for applications that spend most of their time doing computation rather than I/O

Consists of 20 integer benchmarks and 23 floating-point benchmarks written in C, C++, and Fortran

For all of the integer benchmarks and most of the floating-point benchmarks, there are both rate and speed benchmark programs

The suite contains over 11 million lines of code

Rate	Speed	Language	Kloc	Application Area
500.perlbench_r	600.perlbench_s	С	363	Perl interpreter
502.gcc_r	602.gcc_s	С	1304	GNU C compiler
505.mcf_r	605.mcf_s	С	3	Route planning
520.omnetpp_r	620.omnetpp_s	C++	134	Discrete event simulation - computer network
523.xalancbmk_r	623.xalancbmk_s	C++	520	XML to HTML conversion via XSLT
525.x264_r	625.x264_s	С	96	Video compression
531.deepsjeng_r	631.deepsjeng_s	C++	10	AI: alpha-beta tree search (chess)
541.leela_r	641.leela_s	C++	21	AI: Monte Carlo tree search (Go)
548.exchange2_r	648.exchange2_s	Fortran	1	AI: recursive solution generator (Sudoku)
557.xz_r	657.xz_s	С	33	General data compression

Table 2.5 (A)

SPEC CPU2017 Benchmarks

Kloc = line count (including comments/whitespace) for source files used in a build/1000 (Table can be found on page 61 in the textbook.)

Rate	Speed	Language	Kloc	Application Area
503.bwaves_r	603.bwaves_s	Fortran	1	Explosion modeling
507.cactuBSSN_r	607.cactuBSSN_s	C++, C, Fortran	257	Physics; relativity
508.namd_r		C++, C	8	Molecular dynamics
510.parest_r		C++	427	Biomedical imaging; optical tomography with finite elements
511.povray_r		C++	170	Ray tracing
519.ibm_r	619.ibm_s	C	1	Fluid dynamics
521.wrf_r	621.wrf_s	Fortran, C	991	Weather forecasting
526.blender_r		C++	1577	3D rendering and animation
527.cam4_r	627.cam4_s	Fortran, C	407	Atmosphere modeling
	628.pop2_s	Fortran, C	338	Wide-scale ocean modeling (climate level)
538.imagick_r	638.imagick_s	C	259	Image manipulation
544.nab_r	644.nab_s	C	24	Molecular dynamics
549.fotonik3d_r	649.fotonik3d_s	Fortran	14	Computational electromagnetics
554.roms_r	654.roms_s	Fortran	210	Regional ocean modeling.

Table 2.5 (B)

SPEC CPU2017 Benchmarks

Kloc = line count (including comments/whitespace) for source files used in a build/1000 (Table can be found on page 61 in the textbook.)

#### SPEC

	Base		Pe	Peak		
Benchmark	Seconds	Rate	Seconds	Rate	rdome >	
500.perlbench_r	1141	1070	933	1310		
502.gcc_r	1303	835	1276	852		
505.mcf_r	1433	866	1378	901		
520.omnetpp_r	1664	606	1634	617		
523.xalancbmk_r	722	1120	713	1140		
525.x264_r	655	2053	661	2030		
531.deepsjeng_r	604	1460	597	1470		
541.leela_r	892	1410	896	1420		
548.exchange2_r	833	2420	770	2610		
557.xz_r	870	953	863	961		

(Table can be found on page 64 in the textbook.)

	Base		Pe	ak
Benchmark	Seconds	Ratio	Seconds	Ratio
600.perlbench_s	358	4.96	295	6.01
602.gcc_s	546	7.29	535	7.45
605.mcf_s	866	5.45	700	6.75
620.omnetpp_s	276	5.90	247	6.61
623.xalancbmk_s	188	7.52	179	7.91
625.x264_s	283	6.23	271	6.51
631.deepsjeng_s	407	3.52	343	4.18
641.leela_s	469	3.63	439	3.88
648.exchange2_s	329	8.93	299	9.82
657.xz_s	2164	2.86	Table <b>2</b> :119 SPEC CPU 2017	2.92

# Terms Used in SPEC Documentation


#### Benchmark

- A program written in a high-level language that can be compiled and executed on any computer that implements the compiler
  - System under test
- This is the system to be evaluated
  - Reference machine
- This is a system used by SPEC to establish a baseline performance for all benchmarks
  - Each benchmark is run and measured on this machine to establish a reference time for that benchmark

#### Base metric

 These are required for all reported results and have strict guidelines for compilation

- Peak metric
  - This enables users to attempt to optimize system performance by optimizing the compiler output
- Speed metric
  - This is simply a measurement of the time it takes to execute a compiled benchmark
    - Used for comparing the ability of a computer to complete single tasks
- Rate metric
  - This is a measurement of how many tasks a computer can accomplish in a certain amount of time
    - This is called a throughput, capacity, or rate measure
    - Allows the system under test to execute simultaneous tasks to take advantage of multiple processors



**Figure 2.7 SPEC Evaluation Flowchart** 

Benchmark	Seconds	Energy (kJ)	Average Power (W)	Maximum Power (W)
600.perlbench_s	1774	1920	1080	1090
602.gcc_s	3981	4330	1090	1110
605.mcf_s	4721	5150	1090	1120
620.omnetpp_s	1630	1770	1090	1090
623.xalancbmk_s	1417	1540	1090	1090
625.×264_s	1764	1920	1090	1100
631.deepsjeng_s	1432	1560	1090	1130
641.leela_s	1706	1850	1090	1090
648.exchange2_s	2939	3200	1080	1090
657.xz_s	6182	6730	1090	1140

# Summary Chapter 2

#### Performance

## Concepts

- Designing for performance
  - Microprocessor speed
  - Performance balance
  - Improvements in chip organization and architecture
- Multicore
- MICs
- GPGPUs
- Amdahl's Law
- Little's Law

- Basic measures of computer performance
  - Clock speed
  - Instruction execution rate
- Calculating the mean
  - Arithmetic mean
  - Harmonic mean
  - Geometric mean
- Benchmark principles
- SPEC benchmarks



Yürütme Zamanı: (ing. execution time) bir işi başlangıcı ile bitişi arasında geçen süreye denir.

$$Başarım_A \sim \frac{1}{Y \ddot{u}r \ddot{u}tme\ Zamanı_A}$$

Başarım karşılaştırmalı ölçülür.

$$\frac{BaşarımA}{BaşarımB}=n$$



 $Y \ddot{\mathbf{u}} r \ddot{\mathbf{u}} t me \ Zaman_{\mathbf{1}_B} > Y \ddot{\mathbf{u}} r \ddot{\mathbf{u}} t me \ Zaman_{\mathbf{1}_A}$ 

$$\Rightarrow \frac{1}{\textit{Y\"{u}\'{r}\"{u}\textit{t}\textit{tme }\textit{Zaman}\textit{i}_{\textit{A}}} > \frac{1}{\textit{Y\"{u}\'{r}\"{u}\textit{t}\textit{tme }\textit{Zaman}\textit{i}_{\textit{B}}}$$

 $\Rightarrow$  Başarı $m_A >$  Başarı $m_B$ 

# BBÇ(Buyruk Başına Çevrim)



#### Yürütme Zamanı



Yürütme zamanı eşitliğine göre başarımı artırmak (yürütme zamanını azaltmak) için neler yapılabilir?

- Programın içerdiği buyruk sayısını azaltmak.
- Birim buyruk başına geçen çevrim sayısını azaltmak.
- İşlemcinin saat vuruş sıklığını artırmak (ya da çevrim zamanını azaltmak)

# Örnek

Buyruk Türü	A	В	С
BBÇ	1	2	3

Buyruk Sayısı			
Buyruk Türü	A	В	С
Program 1	2	1	2
Program 2	4	1	1

- Hangi program daha fazla buyruk yürütüyor?
  Hangisi daha hızlı çalışır?
  Programların BBÇ değerleri nedir?

## Örnek


100 buyruktan oluşan bir programın kullandığı buyruk türleri ve bu buyruk türlerinin program içindeki oranları verilmiştir. Bu program <u>işlemcisi 500MHz olan</u> bir bilgisayarda kaç saniyede yürütülür?

Buyruk türü	Kullanım yüzdesi	Yürütülmesi için Gereken Çevrim Sayısı
K	%40	1
L	%15	3
M	%35	4
N	%10	5

#### Örnek

Bir programı saat vuruş sıklığı <u>2 GHz</u> olan A bilgisayarı <u>10 saniyede</u> yürütüyor. Bu program A bilgisayarında <u>N sayıda çevrim</u> sürerken B bilgisayarında <u>1,2 N sayıda çevrimde</u> tamamlanıyor. B bilgisayarında bu programın <u>6 saniyede</u> tamamlanmasını istersek B bilgisayarının saat vuruş sıklığı ne olmalıdır?


Bilgisayar	Programın Yürütme Süresi	Programın Çevrim Sayısı	Saat Vuruş Sıklığı
A	10 saniye	N	2 GHz
В	6 saniye	1,2 N	?



Yeni Yürütme Zamanı = ( (1-P) + P/H) )x Eski Yürütme Zamanı

#### Örnek

Bir programın yürütme zamanının %60'ı ondalıklı sayılarla işlemlere harcanmaktadır. Bu programın üzerinde çalışacağı bilgisayarın ondalıklı sayılarla işlemleri 3 kat hızlandırılırsa bu programın yürütme zamanı ne olur?



Yeni Yürütme Zamanı = ( (1-P) + P/H) )x Eski Yürütme Zamanı

#### Örnek

Ondalık sayıların **5 kat** hızlandırılması ile bir programın **3 kat** hızlanması için ondalık sayı işlemlerinin tüm program içerisindeki yüzdesinin ne olması gerekir?

# REFERANSLAR

<a href="https://web.ist.utl.pt/luis.tarrataca/classes/computer\_architecture/C">https://web.ist.utl.pt/luis.tarrataca/classes/computer\_architecture/C</a>
<a href="https://web.ist.utl.pt/luis.tarrataca/classes/computer\_architecture/C">https://web.ist.utl.pt/luis.tarrataca/classes/computer\_architecture/C</a>

<u>InstructionLevelParallelismAndSuperscalarProcessors.pdf</u>

Oğuz Ergin – Bilgisayar Mimarisi Ders Notları