FLX4 controls

PERFORMANCE MAP · 0.3.4
Any content on any deck
Track / arrangement layout below

TEMPO PICKUP. Requires Syndicate's −1…+1 TempoSlider API. OSC Feedback: Toggle All on, including TempoSlider and TempoSliderEnabled. Unknown/off availability blocks tempo writes even without pickup; disable/enable transitions re-arm pickup, not repeated unchanged snapshots.

SHIFT + LOAD
Left: Deck 1 ↔ 3
Right: Deck 2 ↔ 4

FADERS / KNOBS
Mixer + tempo: pickup
Shift + filter: Filter2

BROWSE / LOAD
Turn: up/down · press: enter
Shift + press: back · LOAD: selected deck

TRANSPORT
SYNC tap: sync · hold: master
CUE: hold · Shift + CUE: Grid Start

Decks: hold that side's Shift and tap LOAD. Left 1↔3 and right 2↔4 switch independently; check the console. Other decks keep playing; mixer/tempo pickup re-arms.

Banks: mode button = normal bank; Shift + mode = alternate bank, then release Shift. Shift + pad = that bank's shifted action. Pads 1–4 top; 5–8 bottom.

HOT CUE

Track / clip cues · arrangement override on page 3

1	2	3	4
5	6	7	8

Track only: hold Shift + pad 1–8 for that cue's region loop (cue → next cue/end, quantized). Empty cue: no action. Normal pads still tap cues; Shift + HOT CUE mode selects pitch/formant.

PAD FX · SLIP LOOPS

Hold lengths · bars · tap timing switches

1/32	1/16	1/8	1/4
1/2	— unassigned	D toggle dotted	T toggle triplet

D/T exclusive. Tap active one again for straight. Timing stays selected per deck.

BEAT JUMP

Fixed sizes · all amounts in beats

−1	+1	−2	+2
−4	+4	−8	+8

Hold Shift: −16,+16,−32,+32 / −64,+64,−128,+128. No range cycling.

SAMPLER · LANES

Sampler decks only · selection, not sample hits

1	2	3	4
5	6	7	8

Select a lane; former step-edit banks are unavailable (page 3).

Shift + mode

Shift + mode selects a bank
Release Shift; Shift + pad uses shifted actions

SHIFT + HOT CUE

Pitch / formant · track pitch needs P on

−12 pitch	**−1** pitch	**+1** pitch	**+12** pitch
RESET pitch	**−** formant	**RESET** formant	**+** formant

Formant Mode must be Manual. Formant pads unavailable on clips.

SHIFT + PAD FX

Loop movement / length tools

−1 beat	**+1** beat	**−1** bar	**+1** bar
−4 bars	**+4** bars	**IN** halve*	**OUT** double*

*Halve/double while looping; otherwise sets loop start/end.

SHIFT + BEAT JUMP

Deck tools · sampler unavailable bank on page 3

½ hold speed	**×2** hold speed	**REV** hold	**GRID** start
EARLY hold	**LATE** hold	**RESET** phase	**1×** normal speed

Avoid overlapping speed holds. Releases clear the held switch, not a saved prior state.

SHIFT + SAMPLER

Navigation / locks · sampler unavailable bank on page 3

− zoom	**+** zoom	**PREV** marker page	**NEXT** marker page
ON slip	**OFF** slip	**ON** P / key lock	**OFF** P / key lock

Marker pages: arrangements only. Switch pads set an explicit state.

Clip → documented routes only

PLAY, CUE, Grid Start, hot cues, pitch and phase are translated to Syndicate's Clip routes. Hot cues are taps, not held previews. Clip/Loop means **restart at end**, not a track loop; slip/jump/formant/speed remain blocked.

No hidden jump range. Shift + a mode button selects a bank; holding Shift + a pad is a different gesture. Each deck remembers its bank.

Slip loops → one owner per deck

Tap D or T to select timing; tap the active one again for straight. Hold pad A; hold B to hear B's repeat. Release B while holding A to return to A; release final length to stop repeating without clearing timing.

Timing starts straight per deck. D/T changes during a hold retrigger the active repeat. Mouse edits are not tracked; graceful exit clears D/T. Resuming a loop does not promise to preserve its old region.

Watch the console. It shows LEFT / RIGHT deck, player type, bank and selected repeat timing. Unsupported type-specific controls are blocked, not guessed.

Content-aware control

No fixed deck roles
Syndicate PlayerType feedback selects the layout

Arrangement → marker pages

HOT CUE · AUTOMATIC ARRANGEMENT LAYOUT

1 marker	**2** marker	**3** marker	**4** marker
5 marker	**GRID** start	**PREV** page	**NEXT** page

Five visible markers, then paging. Shift + pads 1–8 are unassigned.

Deck selection → two sides, four decks

LEFT: DECK 1 ↔ 3
Left Shift + left LOAD

RIGHT: DECK 2 ↔ 4
Right Shift + right LOAD

Hold that side’s Shift, tap LOAD, then release Shift. The sides switch independently; startup/restart selects **1 / 2**.

- **Check the console** for the selected deck. Mode lights show the bank, not the deck number.
- **Controls follow selection:** transport, pads, main mixer channel, headphone CUE, LEDs/meter and ordinary LOAD.
- **Other decks keep playing.** Selection does not load, stop, sync or take master. Each deck retains its bank and repeat timing.
- **Pickup re-arms:** mixer and tempo controls wait until hardware reaches Syndicate’s reported position. Missing feedback blocks pickup.

Sampler → step editing unavailable

SAMPLER: pads select lanes 1–8. These do not trigger samples.

SHIFT + BEAT JUMP
Former steps 1–8 · unavailable

–	–	–	–
–	–	–	–

SHIFT + SAMPLER
Former steps 9–16 · unavailable

–	–	–	–
–	–	–	–

Syndicate 0.1.901 removed per-step OSC controls.
Both former step banks have eight unassigned pads and eight unassigned Shift+pads. They cannot edit steps.

Use Syndicate itself for step editing; the bridge does not invent another OSC route. No pad step-state LEDs, velocity editing, lane mute or direct sample hits are assigned.

Setup: use Syndicate four-deck view; disable direct FLX4 MIDI. Enable OSC input 9090, feedback to 127.0.0.1:9096 and Toggle All (including TempoSliderEnabled). Feedback is change-only, with no rate setting. Default profile/wire root: `/Syndicate/`; custom roots must match in Syndicate and `settings.json`. See README.md and root rules.

Boundaries: controls may need to be visible in Syndicate. No jog/scratch, crossfader, held cue preview or arrangement-internal mixing. Shift+HOT CUE pad loops work on tracks only; they are cue regions, not fixed beat lengths. Use 4BEAT/EXIT to leave one. Stop/restart after an app restart or uncertain state; Ctrl+C attempts releases, but UDP loss/force-kills cannot guarantee delivery.

FLX4 FX macros

Optional profile capability · enabled in bundled layout
Four channels, current selected decks

CONFIGURE SYNDICATE FIRST. On all four main mixer channels, enable an insert chain and assign Macro 1 to the plugin's wet/dry (0 dry → 1 wet); Macro 2 to a mappable plugin enable (0 off, 1 on). Invert a bypass mapping if needed. The bridge does not configure inserts, toggle the whole chain or change wet amount on enable.

FX CH SELECT · 1
Current left deck (1 or 3)

FX CH SELECT · 2
Current right deck (2 or 4)

FX CH SELECT · 1&2
Both selected decks, not all four

SELECTOR / DECK CHANGE
No OSC · re-arm wet dry-home

Startup target is unknown until paired left/right hardware selector reports arrive; no guessed initial target. Left/right deck selection via Shift+LOAD also retargets FX. In 1&2 both selected main mixer channels receive the same value, including explicit on/off.

LEVEL/DEPTH → Macro 1 wet

14-bit knob position sends normalized `Mixer/CHn/FX/Macro/1`. Without documented macro feedback, this is **not feedback pickup**: the first complete knob report after activation or retarget only establishes a baseline.

1. Physically turn to **exact 0/dry** to send 0 and arm. If already dry, nudge away then back.
2. Subsequent movement sends 0–1 wet to the selected channel(s).

Another known bridge writer of that route (including LC3) re-arms dry-home. Mouse/external plugin edits have no writer identity and cannot be tracked without feedback.

FX ON/OFF → Macro 2 enable

FX ON/OFF: explicit `Mixer/CHn/FX/Macro/2` = **1 on**. **Either Shift + FX ON/OFF:** explicit **0 off**. Not a toggle; it does not alter Macro 1 wet or the entire insert chain.

The FX LED is **not driven**: it does not show effect state. No macro feedback subscription or startup/shutdown macro writes. OSC sends do not confirm the plugin acted. FX SELECT pushbutton, BEAT arrows and Macros 3–8 remain unassigned.

Operation boundary: Only the FLX4 EFFECT controls above map to these macros; PAD FX remains the slip-loop bank (page 1). External plugin settings are yours to configure. Hardware and Syndicate end-to-end behaviour remain unverified.