MATERIALS LIST

Obtain the following materials before begining assembly:

1. Acrylic Glue



2. Acrylic Glue Syringe



For acrylic gluing instructions, review the below video link: https://www.youtube.com/watch?v=hT6OwcBTps

3. Set square



4. Glue gun and glue stick




5. Screw and bolt





Ensure that screws are no wider than 2mm, and at least 15mm long.

PLEXI-GLASS













03 First glue part A5, and then glue part A14.


























































21 Create the plunger by hot glueing (glue gun) the wood dowels to all A29 parts.



22 Drill a hole into the base of the cartridges that is large enough to fit the wood dowel.




12 Hot glue (glue gun) all A30 parts to cartridges.




Insert plungers into cartridges.




25 First insert the top peg of the cartridge into the hinge.



 $26\,$ Gently rotate cartridge downwards to lock the bottom peg into the hinge.



27 Gently swing the cartridge shut.



28 HABITAT A IS COMPLETE.

