Assembly Instructions

Sentinel Composites Full Fender (Cat# 5343-2)



Items Included in this kit:

- (4) poly half fenders Cat# 5340
- (2) poly connector bridges Cat# 5382
- (2) metal stiffener plates. $(2\frac{1}{2})^n$ x 22")
- (1) Hardware Kit Cat# N10506672:
 - (24) bolts with button top Allen head
 - (24) Teflon Lock nuts
 - (48) washers
 - (4) Kelron bracket spacer. $(1\frac{1}{2}$ " x 5")


Tools required for assembly

Drill with \(^3\)\end{8}-inch bit and \(^5\)\end{9}-inch bit \(^3\)\end{4}-inch open end wrench or socket Allen wrenches \(^2\) C-clamps or pinch clamps

- 1. Assemble two half fenders end-to-end and install connector bridge over 2-inch lip. Be sure bridge is seated securely use clamps to ensure secure positioning.
- 2. Drill the eight ½-inch holes through the fenders using connector bridge as guide.
- 3. Secure the connector bridge to the fenders using 8 sets of bolts/washers/Teflon Lock nuts. Be sure that Allen head is to the outside. Assemble

with a washer on the top and on the bottom.

- 4. Drill the 4 holes through the connector bridge that secure the 2-inch flange ends.
- 5. Insert a stiffener plate between the two fender pieces and align holes before inserting bolts.
- 6. Secure with 4 sets of bolts/washers/Teflon Lock Nuts.



Installing Mounting Plate for EZ-Mount Center bracket.

- 1. Position mount plate on fender assembly closest to truck cab.
- 2. Drill four $\frac{3}{8}$ " holes through connector bridge/fender corresponding with EZ-Mount plate.
- 3. Insert four $\frac{3}{8} \times \frac{1}{2}$ bolts from top of fender assembly.
- 4. Position 1 Kelron spacer mount over bolts.
- 5. Place EZ_Mount fender mounting plate over spacers and bolts and secure with \(^3\)\epsilon^" Teflon Lock nuts



