Ansys nonlinearities can be grouped into three classes :

- 1. Material Stress is not proportional to strain.
 Applications include plasticity, creep,
 hyperelasticity and swelling.
- 2. Geometric The load path changes as a function of displacements. Stress stiffening, buckling, and large deflection/rotation problems exhibit geometric nonlinearities.
- 3. Element Element stiffness changes as a function of some parameter. Gap elements are an example of this type.