

## **Productverslag**

The goal of this product is to make a remote controlled card shooter. It makes use of Bluetooth to receive a set of commands. To operate the the machine use the following guide:


1. Install the "Serial Bluetooth Terminal" on your phone.




- 2. Turn on the device (Kaarten Shieter) and the Bluetooth on your phone.
  - Normally you should see the name "Kaarten Shieter" show up. Pair with it.




- 3. Click on the hamburger button to open the side tab. Click on the "Devices" tab. Scroll down until you see the "Kaarten Shieter" and click on it.
  - You should be connecting to the device.
  - If you cannot connect to the device, it means that the antenna isn't exposed enough. Remove the lid from the device.





Note: When the device will always wait until at least one master is connected. When the connected has been severed it will start this waiting again. Just repeat steps 3 to reconnect to it.

- 4. The device accepts three commands:
  - 'I' (Left): Rotates the device to the left.
  - 'r' (Right): Rotates the device to the right.
  - 's' (Shoot): Starts shooting cards.



Note: The buttons on the bottom can be used to set these commands. By pressing them and holding down.

