16.317: Microprocessor Systems Design I

Spring 2013

Lecture 28: Key Questions April 12, 2013

1. Describe how to work with multi-byte data.

- 2. Translate these x86 operations to PIC code. Assume that there are registers defined for each x86 register (e.g. AL, AH, BL, BH, etc.). 16-bit values (e.g., AX) must be dealt with as individual bytes
- MOVZX AX, BL

• MOVSX AX, BL

• INC AX

• SUB BX, AX

• RCL AX, 5