## 16.317: Microprocessor Systems Design I

Fall 2015

Lecture 28: Key Questions November 13, 2015

1. Describe the assembler directives that can be used in the MPLAB IDE.

2. Explain the operation of the following assembly program, which lights a single LED:

## Start:

741 C •			
k	oanksel	TRISC	;select bank1
k	ocf	TRISC,0	;make CO an output
k	oanksel	LATC	;select bank2
(	clrf	LATC	;initialize the
			; LATCH by
			; turning off
			; everything
k	osf	LATC, 0	;turn on LED CO (DS1)
(	goto	\$	;sit here forever!
er	nd		

M. Geiger Lecture 28: Key Questions

3. Explain the equivalent program in C, shown below:

```
void main(void) {
    TRISCbits.TRISC0 = 0;  // Pin 0 = output
    LATC = 0; //clear all pins to 0
    LATCbits.LATC0 = 1; // turn ON LED
    while(1) continue;
}
```

4. Describe how to compile and run code in MPLAB. Explain the differences between running code in the simulator and on the development board. Also, discuss how to use the in-circuit debugger to access code on the chip as it runs.

## 5. Describe the following assembly program, which blinks a single LED:

```
cblock 0x70 ; shared memory accessible from all banks
Delay1
              ; Two registers for delay loop in shared mem
Delay2
    endc
   ORG 0
Start:
    banksel
                  OSCCON
                                 ;bank1
    movlw
                  b'00111000'
                                 ;set cpu speed of 500KHz
                                 ;OSCCON configures
    movwf
                  OSCCON
                                 ; internal clock
                                ;Pin C0 = output for DS1
    bcf
                  TRISC, 0
    banksel
                   LATC
                                ;bank2
    clrf
                   LATC
                                 ;Turn off all of the LEDs
MainLoop:
                   LATC, 0
                                ;turn on DS1
   bsf
OndelayLoop:
    decfsz
                   Delay1,f
                                ;Waste time.
    bra
                   OndelayLoop ; Inner loop takes 3 inst
                            ; per loop * 256 loops =
                                 ; 768 instructions
                   Delay2,f
                                 ; The outer loop takes an
    decfsz
                                 ; additional 3
                                 ; instructions per loop
                                 ; * 256 loops
                   OndelayLoop
                                 ; (768+3) * 256 = 197376
    bra
                                 ; instructions /
                                 ; 125K instructions per
                                 ; second = 1.579 sec
                                 ;Turn off LED CO
    bcf
                   LATC, 0
OffDelayLoop:
    decfsz
                   Delay1,f ;same delay as above
                   OffDelayLoop
    bra
    decfsz
                   Delay2, f
    bra
                   OffDelayLoop
                   MainLoop ; Do it again...
    bra
    end
```

M. Geiger Lecture 28: Key Questions

## 6. Describe the equivalent program in C, shown below:

```
void main(void) {
   unsigned int delay; // 16 bit variable

   OSCCON = 0b00111000; //500KHz clock speed
   TRISCbits.TRISCO = 0; //using pin as output
   delay = 11250;
   while (1) {
      //each instruction is 8us (1/(500KHz/4))
      while(delay-- != 0)continue;

   LATCbits.LATCO ^= 1; //toggle LED
      delay = 11250; //reset delay counter
   }
}
```