## **EECE.3170: Microprocessor Systems Design I**

Fall 2016

## Homework 7 Solution

For each of the following complex operations, write a sequence of PIC 16F1829 instructions that performs an equivalent operation. Assume that X, Y, and Z are 16-bit values split into individual bytes as shown in the following cblock directive, which defines two additional variables you can use:

```
cblock 0x70
    XH, XL
              ; High and low bytes of X
            ; High and low bytes of Y
     YH, YL
             ; High and low bytes of Z
     ZH, ZL
              ; Temporary byte, if needed
     TEMP
endc
```

a. Perform the 16-bit addition: X = Y + Z. Do not change Y or Z when performing this operation.

Solution: First, we'll look at the inefficient method, which would work on any PIC microcontroller:

```
movf
            YL, W
                        ; Copy YL to XL
movwf
            XL
movf
            YH, W
                        ; Copy YH to XH
movwf
            XH
            ZL, W
movf
                        ; Add low bytes
            XL, F
addwf
btfsc
            STATUS, C; Account for carry
incf
            XH, F
movf
            ZH, W
                        ; Add high bytes
addwf
            XH. F
```

We can do this operation more efficiently by using the addwfc instruction found on microcontrollers like the PIC16F1829, which allows you to get rid of the extra instructions that "account for the carry:"

movf movwf	YL, W XL	; Copy YL to XL
movf	YH, W	; Copy YH to XH
movwf	XH	· Add low bytoo
movf addwf	ZL, W XL, F	; Add low bytes
movf	ZH, W	; Add high bytes, including carry from low byte
addwfc	XH, F	

EECE.3170: Microprocessor Systems Design I Fall 2016

b. Perform the 16-bit subtraction: X = Y - Z. Do not change Y or Z when performing this operation.

Instructor: M. Geiger

Homework 7 Solution

**Solution:** This operation is very similar to 16-bit addition, although you have to be more careful about what register is moved into the working register before the subtract instructions. First, the inefficient version—remember that C = 0 if a borrow occurs:

YL, W movf ; Copy YL to XL movwf XL YH, W ; Copy YH to XH movf movwf XH ZL, W ; Subtract low bytes movf subwf XL, F STATUS, C; Account for borrow ( $C = 0 \rightarrow$  "borrow" = 1) btfss XH, F decf movf ZH, W ; Subtract high bytes subwf XH, F

And the more efficient version that uses the "subtract with borrow" subwfb instruction:

movf YL, W ; Copy YL to XL movwf XL YH, W ; Copy YH to XH movf movwf XΗ ZL, W movf ; Subtract low bytes subwf XL, F movf ZH, W ; Subtract high bytes, taking borrow into XH, F subwfb ; account

c. Perform a 16-bit arithmetic right shift: X = Y >> ZL. (Note that, because the shift amount is no greater than 15, a single byte is sufficient to hold that value.) Do not change Y or ZL when performing this operation.

Instructor: M. Geiger

Homework 7 Solution

<u>Solution:</u> Similarly to the last two problems, the first thing to be done is move the value to be shifted into the destination registers XH and XL. Once that's done, set up a loop with ZL iterations (we'll have to copy that value to another register so it's not changed) and do the shift. Remember, while the shift for the high byte can be an arithmetic shift, we need a rotate instruction to change the low byte so that the bit shifting between bytes is correctly accounted for.

	movf movwf	YL, W XL	; Copy YL to XL
	movf movwf	YH, W XH	; Copy YH to XH
	movf movwf	ZL, W TEMP	; Copy ZL to TEMP
L:	asrf rrf decfsz goto	XH, F XL, F TEMP, F L	<ul> <li>; Shift upper byte (C = bit to be shifted into XL)</li> <li>; Shift lower byte</li> <li>; Decrement loop counter and return to start</li> <li>; of loop if there are more iterations.</li> </ul>

Instructor: M. Geiger Homework 7 Solution

d. Given an 8-bit variable, YL, perform the multiplication:

$$YL = YL * 10$$

<u>Hint:</u> Note that multiplication by a constant amount can be broken into a series of shift and add operations. For example, in general:

- X \* 2 can be implemented by shifting X to the left by I (X << 1)
- X \* 5 can be implemented as (X \* 4) + X = (X << 2) + X

**Solution:** Recognize that YL \* 10 = (YL \* 8) + (YL \* 2) = (YL << 3) + YL + YL

movf YL, W; Copy original value of YL into TEMP

movwf TEMP

movlw 3 ; Set W = 3—use as loop counter for left shift

L: Islf YL, F

addlw -1 ; Decrement loop counter

btfss STATUS, Z; and exit once it reaches 0

goto L

movf TEMP, W; W = TEMP = original value of YL

; At this point, YL = (original YL) << 3

; = (original YL) \* 8

addwf YL, F; YL = (original YL) \* 9

addwf YL, F; YL = (original YL) \* 10

e. Given two 8-bit variables stored in XL and YL, copy the value of bit position YL within variable XL into the carry flag. For example:

Instructor: M. Geiger

Homework 7 Solution

- If XL = 0x03 and YL = 0x00, set C to the value of bit 0 within XL. • Since  $XL = 0x03 = 0000 \ 0011_2$ , C = 1
- If XL = 0xC2 and YL = 0x04, set C to the value of bit 4 within XL. • Since  $XL = 0xC2 = 1100\ 0011_2$ , C = 0

## *Note that:*

- This operation is very similar to the bit test (BT) instruction in the x86 architecture.
- Since YL is not a constant, you cannot use the value of YL directly in any of the PIC bit test instructions (for example, btfsc XL, YL is not a valid instruction).
- Your code should not modify either XL or YL.

## **Solution**

	<del></del>		
	movlw	0x01	; TEMP will hold bit mask used
	movwf	TEMP	; to isolate bit YL within XL
	movf	YL, W	; Copy B to W—determines # of times to shift temp
L:	btfsc	STATUS, Z	; Once W hits 0, end loop—bit mask is set
	goto	L2	; Must test this first for case where YL == 0
	rlf	TEMP, F	; TEMP will eventually be 1 << YL
	addlw	-1	; Decrement W
	goto	L	
L2:	bcf	STATUS, C	; Clear C
	movf	TEMP, W	; AND temp with XL to mask out all but bit YL
	andwf	XL, W	•
	btfss	STATUS, Z	; If result is non-zero, set C bit; otherwise,
	bsf		; leave as 0