EECE.3170: Microprocessor Systems Design I

Summer 2016

Lecture 12: Key Questions June 16, 2016

1. Describe the assembler directives that can be used in the MPLAB IDE.

2. Explain the operation of the following assembly program, which lights a single LED:

Start:

banksel	TRISC	;select bank1
bcf	TRISC,0	;make CO an output
banksel	LATC	;select bank2
clrf	LATC	;initialize the
		; LATCH by
		; turning off
		; everything
bsf	LATC, 0	;turn on LED C0 (DS1)
goto	\$;sit here forever!
end		

3. Explain the equivalent program in C, shown below:

```
void main(void) {
    TRISCbits.TRISC0 = 0;  // Pin 0 = output
    LATC = 0; //clear all pins to 0
    LATCbits.LATC0 = 1; // turn ON LED
    while(1) continue;
}
```

4. Describe how to compile and run code in MPLAB. Explain the differences between running code in the simulator and on the development board. Also, discuss how to use the in-circuit debugger to access code on the chip as it runs.

M. Geiger

5. Describe the following assembly program, which blinks a single LED:

```
cblock 0x70
              ; shared memory accessible from all banks
Delay1
              ; Two registers for delay loop in shared mem
Delay2
    endc
   ORG 0
Start:
    banksel
                  OSCCON
                                 ;bank1
                  b'00111000'
                                 ;set cpu speed of 500KHz
    movlw
    movwf
                                 ;OSCCON configures
                  OSCCON
                                 ; internal clock
                                ;Pin C0 = output for DS1
    bcf
                  TRISC, 0
    banksel
                   LATC
                                 ;bank2
                   LATC
                                 ;Turn off all of the LEDs
    clrf
MainLoop:
                   LATC, 0
   bsf
                               ;turn on DS1
OndelayLoop:
                               ;Waste time.
    decfsz
                   Delay1,f
                                 ; Inner loop takes 3 inst
    bra
                   OndelayLoop
                            ; per loop * 256 loops =
                                 ; 768 instructions
    decfsz
                   Delay2,f
                                 ; The outer loop takes an
                                 ; additional 3
                                 ; instructions per loop
                                 ; * 256 loops
                                 (768+3) * 256 = 197376
    bra
                   OndelayLoop
                                 ; instructions /
                                 ; 125K instructions per
                                 ; second = 1.579 sec
                                 ;Turn off LED CO
    bcf
                   LATC, 0
OffDelayLoop:
    decfsz
                   Delay1,f ; same delay as above
    bra
                   OffDelayLoop
    decfsz
                   Delay2,f
                   OffDelayLoop
    bra
                   MainLoop ; Do it again...
    bra
    end
```

1. Extra space to describe first program.


6. Describe the equivalent program in C, shown below:

```
void main(void) {
   unsigned int delay; // 16 bit variable

   OSCCON = 0b00111000; //500KHz clock speed
   TRISCbits.TRISCO = 0; //using pin as output
   delay = 11250;
   while (1) {
        //each instruction is 8us (1/(500KHz/4))
        while(delay-- != 0)continue;

        LATCbits.LATCO ^= 1; //toggle LED
        delay = 11250; //reset delay counter
    }
}
```

7. Describe the basic functionality of the PIC16F1829 clock generation module below:



8. Explain the operation of the programs used to rotate the LEDs using an instruction count-based delay loop (rotate.asm and rotate.c).

9. Explain the features of a typical microcontroller timer module.

M. Geiger Lecture 12: Key Questions

10. Explain the operation of the programs used to rotate the LEDs using a timer-based delay loop (timer0.asm and timer0.c).

```
***********************
; Lesson 3 - "Rotate"
 This lesson will introduce shifting instructions as well as bit-oriented skip operations to
; move the LED display.
; LEDs rotate from right to left at a rate of 1.5s
; PIC: 16F1829
; Assembler: MPASM v5.43
; IDE: MPLABX v1.10
 Board: PICkit 3 Low Pin Count Demo Board
; Date: 6.1.2012
 *************************
 * See Low Pin Count Demo Board User's Guide for Lesson Information*
 ***********************************
#include <p16F1829.inc>
     _CONFIG _CONFIG1, (_FOSC_INTOSC & _WDTE_OFF & _PWRTE_OFF & _MCLRE_OFF & _CP_OFF & _CPD_OFF &
   _BOREN_ON & _CLKOUTEN_OFF & _IESO_OFF & _FCMEN_OFF);
    __CONFIG _CONFIG2, (_WRT_OFF & _PLLEN_OFF & _STVREN_OFF & _LVP_OFF);
                                     ;supress the 'not in bank0' warning
   errorlevel -302
   cblock 0x70
                                     ;shared memory location that is accessible from all banks
Delay1
                                     ;define two file registers for the delay loop in shared memory
Delay2
    endc
    ; -----LATC-----
   ; Bit#: -7---6---5---4---3---2---1---0---
   ; LED: -----|DS4|DS3|DS2|DS1|-
    ; -------
   ORG 0
                                     ;start of code
Start:
    banksel
                  OSCCON
                                     ;bank1
                                     ;set cpu clock speed of 500KHz
    movlw
                  b'00111000'
    movwf
                  OSCCON
                                     ;move contents of the working register into OSCCON
    clrf
                  TRISC
                                     ;make all of PORTC an output
    banksel
                  LATC
                                     ;select the bank where LATC is (bank2)
    movlw
                  b'00001000'
                                     ;start the rotation by setting DS4 ON
    movwf
                  LATC
                                     ;write contents of the working register to the latch
MainLoop:
OndelayLoop:
    decfsz
                  Delay1,f
                                     ;Waste time.
                  OndelayLoop
                                     ;The Inner loop takes 3 instructions per loop * 256 loopss = 768
    goto
   instructions
    decfsz
                  Delay2,f
                                     ;The outer loop takes an additional 3 instructions per lap * 256
   loops
                  OndelayLoop
                                     ;(768+3) * 256 = 197376 instructions / 125K instructions per second ✔
    goto
    = 1.579 \text{ sec.}
Rotate:
   lsrf
                  LATC, F
                                     ; shift the LEDs and turn on the next LED to the right
                  STATUS, C
                                     ;did the bit rotate into the carry (i.e. was DS1 just lit?)
   htfsc
   bsf
                  LATC, 3
                                     ;yes, it did and now start the sequence over again by turning on
   DS4
                  MainLoop
                                     ;repeat this program forever
   goto
   end
                                     ;end code section
```

```
**********************
* Lesson 3 - "Rotate"
* This lesson will introduce shifting instructions as well as bit-oriented skip operations to
 * move the LED display.
* LEDs rotate from right to left at a rate of 1.5s
* PIC: 16F1829
* Compiler: XC8 v1.00
* IDE: MPLABX v1.10
* Board: PICkit 3 Low Pin Count Demo Board
* Date: 6.1.2012
* See Low Pin Count Demo Board User's Guide for Lesson Information*
*/
#include <htc.h>
                                              //PIC hardware mapping
#define _XTAL_FREQ 500000
                                              //Used by the XC8 delay_ms(x) macro
//config bits that are part-specific for the PIC16F1829
CONFIG(FOSC INTOSC & WDTE OFF & PWRTE OFF & MCLRE OFF & CP OFF & CPD OFF & BOREN ON & CLKOUTEN OFF &
   IESO OFF & FCMEN_OFF);
 _CONFIG(WRT_OFF & PLLEN_OFF & STVREN_OFF & LVP_OFF);
   /* -----LATC-----
    * Bit#: -7---6---5---4---3---2---1---0---
    * LED: -----|DS4|DS3|DS2|DS1|-
    *-----
void main(void) {
                                              //all pins are outputs
   TRISC = 0;
   OSCCON = 0b00111000;
                                              //500KHz clock speed
   LATC = 0b0001000;
                                              //start the rotation by setting DS4 ON - rotate
   from the right to left
   while (1) {
          delay_ms(500);
                                              //delay 500ms
          LATC >> = 1;
                                              //shift to the right by 1
                                              //when the last LED is lit, restart the pattern
          if(STATUSbits.C)
             LATCbits.LATC3 = 1;
   }
}
```

```
***********************
; Lesson 9 - Timer0
; Timer0 is a counter implemented in the processor. It may be used to count instruction
; cycles or external events, that occur at or below the instruction cycle rate.
; In the PIC18, Timer0 can be used as either an 8-bit or 16-bit counter, or timer. The
; enhanced mid-range core implements only an 8-bit counter.
; This lesson configures Timer0 to count instruction cycles and to set a flag when it rolls
; over. This frees up the processor to do meaningful work rather than wasting instruction
; cycles in a timing loop.
; Using a counter provides a convenient method of measuring time or delay loops as it
; allows the processor to work on other tasks rather than counting instruction cycles.
; LEDs rotate from right to left, similar to Lesson 3, at a rate of ~.5 seconds.
; PIC: 16F1829
; Assembler: MPASM v5.43
; IDE: MPLABX v1.10
; Board: PICkit 3 Low Pin Count Demo Board
; Date: 6.1.2012
 *************************
 * See Low Pin Count Demo Board User's Guide for Lesson Information*
#include <p16F1829.inc>
      _CONFIG _CONFIG1, (_FOSC_INTOSC & _WDTE_OFF & _PWRTE_OFF & _MCLRE_OFF & _CP_OFF & _CPD_OFF &
    BOREN_ON & _CLKOUTEN_OFF & _IESO_OFF & _FCMEN_OFF);
    __CONFIG _CONFIG2, (_WRT_OFF & _PLLEN_OFF & _STVREN_OFF & _LVP_OFF);
    errorlevel -302
                                     ;surpress the 'not in bank0' warning
    ; -----LATC-----
    ; Bit#: -7---6---5---4---3---2---1---0---
   ; LED: -----|DS4|DS3|DS2|DS1|-
    ; -----
    Org 0
Start:
                                     ;Setup main init
    banksel
                  OSCCON
                                     :bank1
                  b'00111000'
    movlw
                                     ;set cpu clock speed to 500KHz
    movwf
                  OSCCON
                                     ;move contents of the working register into OSCCON
                                     ;Configure the LEDs
    banksel
                  TRISC
                                     ;bank1
    clrf
                  TRTSC
                                     ;make all of PORTC an output
    banksel
                  ΙΔΤΟ
                                     ;bank2
    movlw
                  b'00001000'
                                     ;start with DS4 lit
    movwf
                   LATC
                                     ;Setup Timer0
    banksel
                  OPTION REG
                                     ;bank1
    movlw
                  b'00000111'
                                     ;1:256 prescaler for a delay of: (insruction-cycle * 256-counts)*
   prescaler = ((8uS * 256)*256) = 524mS
    movwf
                  OPTION REG
MainLoon:
   btfss
                  INTCON, TMR0IF
                                     ;did TMR0 roll over yet?
   bra
                   $-1
                                     ;wait until TMR0 overflows and sets TMR0IF
                   INTCON, TMR0IF
   bcf
                                     ;must clear flag in software
                                     ;rotate the LEDs
```

banksel LATC ;bank2
lsrf LATC, f
btfsc STATUS,C ;did the bit rotate into the carry?
bsf LATC,3 ;yes, put light DS4 back up
bra MainLoop ;continue forever
end

```
**********************
 *
   Lesson 9 - "Timer0"
 * Timer0 is a counter implemented in the processor. It may be used to count instruction
 * cycles or external events, that occur at or below the instruction cycle rate.
 * In the PIC18, Timer0 can be used as either an 8-bit or 16-bit counter, or timer. The
 * enhanced mid-range core implements only an 8-bit counter.
* This lesson configures Timer0 to count instruction cycles and to set a flag when it rolls
^{st} over. This frees ar{\text{up}} the processor to do meaningful work rather than wasting instruction
 * cycles in a timing loop.
   Using a counter provides a convenient method of measuring time or delay loops as it
   allows the processor to work on other tasks rather than counting instruction cycles.
 st LEDs rotate from right to left, similar to Lesson 3, at a rate of \sim.5 seconds.
* PIC: 16F1829
   Compiler: XC8 v1.00
 * IDE: MPLABX v1.10
   Board: PICkit 3 Low Pin Count Demo Board
   Date: 6.1.2012
* ************************************
* See Low Pin Count Demo Board User's Guide for Lesson Information*
*/
#include <htc.h>
                                                  //PIC hardware mapping
                                                  //Used by the XC8 delay_ms(x) macro
#define _XTAL_FREQ 500000
//config bits that are part-specific for the PIC16F1829
__CONFIG(FOSC_INTOSC & WDTE_OFF & PWRTE_OFF & MCLRE_OFF & CP_OFF & CPD_OFF & BOREN_ON & CLKOUTEN_OFF &
   IESO_OFF & FCMEN_OFF);
 _CONFIG(WRT_OFF & PLLEN_OFF & STVREN_OFF & LVP_OFF);
   /* -----LATC-----
    * Bit#: -7---6---5---4---3---2---1---0---
    * LED: -----|DS4|DS3|DS2|DS1|-
    *______
    */
void main(void) {
   OSCCON = 0b00111000;
                                                 //500KHz clock speed
   TRISC = 0;
                                                 //all LED pins are outputs
   LATC = 0:
   OPTION REG = 0b00000111;
                                                //1:256 prescaler for a delay of: (insruction-cycle * 

✓
   256-counts)*prescaler = ((8uS * 256)*256) =~ 524mS
   LATCbits.LATC4 = 1;
                                                //start with DS4 lit
   while (1) {
       while (!INTCONbits.TMR0IF) continue;
                                                //you can let the PIC do work here, but for now we will ∠
    wait for the flag
       INTCONbits.T0IF = 0;
                                                //flag MUST be cleared in software
       LATC >> = 1;
                                                //rotate the LEDs
       if (STATUSbits.C)
                                                //when the last LED is lit, restart the pattern
           LATCbits.LATC3 = 1;
   }
```

}