PINBALL 2000 SCHEMATIC MANUAL

INCLUDING CABINET AND BACKBOX PARTS

Williams Electronics Games, Inc. 3401 North California Avenue Chicago, IL 60618

TABLE OF CONTENTS

CABINET AND BACKBOX PARTS	1
POWER WIRING	2
AUDIO AMP SCHEMATIC	4
PRISM ROM DAUGHTER SCHEMATIC	5
PRISM MAIN SCHEMATIC	6
POWER DRIVER SCHEMATIC	9

Part Number **Description** 04-12480.4 Cabinet Leg Mounting Bracket (x4) 2 01-11400-1 A-19514-6 Leg Assembly - Black Ridge (x4) 3 08-7377 Lea Leveler/Adjuster (x4) 01-15132-1 Playfield Slide Track - Right 04-12610 Stay Arm Lockdown Bracket Assembly A-22996 Speaker, 6.5" Woofer, 4ç 8 5555-16059-00 A-22966 Power Control Box Assembly 10 04-12596.1 Drip Plate 5610-15930-00 Transformer Assembly 11 A-22998 **Driver Board Cover Assembly** 12 Driver Board Back Plate 13 01-15146 14 04-12329 Power Driver Board PCB Assembly 15 03-10011 Cover Stop Tube 09-96012-33 Coin Door - USA 16 17 20-10690 Hand Molding Lock 18 A-22984 Flipper Button Assembly (x2)

19 See Game Manual Push Button w/Switch 20 01-15184 Launch Button Bracket See Game Manual 21 Push Button w/Switch 22 A-23024

Coin Door Interlock Switch Assembly 23 A-22964 Coin door Interface PCB Assembly & Spacer

24 A-17195-2 Tilt Switch Assembly w/Cable 25 04-10346.1 Tilt Mechanism Assembly

26 20-6502-A Plumb Bob

27 A-23139 4-Ball Cash Box Assembly Hand Molding Assembly 28 A-22997 29 A-22976-1 Side Molding Assembly (x2) 30 04-12739.1 Tinted Playfield Glass Assembly

31 03-8091 Rear Molding 32 01-15214 Hole Cover

33 01-15212 Cabinet Corner Bracket

Miscellaneous Parts: (Not Shown)


Part Number Description 01-15132-2 Playfield Slide Track - Left 04-12628.2 Safety Pin Bracket 01-15136-1-2 Lock Plate See Game Manual Cordset


20-6500 Steel Ball, &1 1/16" (x4) 01-6389-1 Cash Box lock Bracket

Cabinet Cables:

Part Number Description H-22740-2.1 Cabinet Cable H-22740-1.2 Cabinet Cable H-22736

Secondary Power Cable See Game Manual Cabinet Power/Speaker Cable See Game Manual Cabinet Switch/Lamp Cable





Item	Part Number	Description
1	04-12489.4	Back Box
2	A-22982	Back Boor Assembly
3	01-15131	Door Channel
4	03-9992	Knob
5	A-22981	Lock & Plate Assembly
6	01-15134	Front Lock Cam
7	A-22975-50070	Marquee Assembly
8	04-12607.1	Speaker Grill Bracket
9	01-12606.1	Speaker Grill
10	5555-15580-00	Speaker - 4c, 25W
11	5675-16058-01	Monitor – 19"
12	01-15130.1	Computer Case Mounting Bracket
13	See Game Manual	Computer Case Assembly
14	A-22980	Fluorescent Lamp Assembly
		•
<u>ltem</u>	Part Number	<u>Description</u>
15		Fluorescent Lamp 15W, 18"
16		Ballast Mounting Bracket
17	A-23155	Ballast Assembly
18		CPU/AC Power Cable
19		AC/Speaker Cable
20	20-10583	Extension Cable db09 - 10ft


Miscellaneous Parts:

20-10584


21

<u>ltem</u>	Part Number	<u>Description</u>
22	11-1464	Back Box Shipping Brace
23	5556-15272-00	Ferrite


Extension Cable db25 - 10ft





POWER WIRING, sheet 1 of 2 PAGE 2



POWER WIRING, sheet 2 of 2 PAGE 3







PAGE 5

