2. ARRIVAL (CONTD)

2.1. AIRCRAFT OPERATIONAL PROCEDURES (contd)

Stands from 91 to 102, 103A, 103B, 104A, 104B

For landing aircraft

- Rwy 25L: Rwy 25L/07R Twy S7/S8/S10 Twy V/(Twy S Twy S8/S7/V1/S6 Twy V) -- taxilane Y8/Y7/Y6/Y1 - taxilane Y - stands.
- Rwy 25R: Rwy 25R/07L (Twy P5 Twy S8)/(Twy P6 Twy S10)/(Twy P4 Twy P5 -
- Twy S8) Twy V/(Twy S Twy S7/V1/S6 Twy V) taxilane Y8/Y7/Y6/Y1 taxilane Y - stands.
- Rwy 07L: Rwy 07L/25R Twy P2/P1/(Twy P3 Twy P2/P1) Twy S5/(Twy S4 Twy S/V -
- Twy S5) Twy V/(Twy S Twy S6/V1/S7 Twy V) taxilane Y1/Y6/Y7/Y8 taxilane Y -
- Rwy 07R: Rwy 07R/25L Twy S5/S4/S3/S1 Twy V/(Twy S Twy S5/S6/V1/S7 Twy V) -- taxilane Y1/Y6/Y7/Y8 - taxilane Y - stands.

Stands 103, 104

For landing aircraft

- Rwy 25L: Rwy 25L/07R Twy S7/S8/S10 Twy V/(Twy S10 Twy S Twy S8/S7 Twy V) -- taxilane Y7 - assigned stand.
- Rwy 25R: Rwy 25R/07L (Twy P5 Twy S8)/(Twy P6 Twy S10)/(Twy P4 Twy P5 -
- Twy S8) Twy V/(Twy S Twy S7/S8 Twy V) taxilane Y7 assigned stand.
- Rwy 07L: Rwy 07L/25R Twy P2/P1/(Twy P3 Twy P2) Twy S5/(Twy S4 Twy S/V -
- Twy S5) Twy V/(Twy S Twy S6/V1 Twy V) taxilane Y7 assigned stand.
- Rwy 07R: Rwy 07R/25L Twy S5/S4/S3/S1 Twy V/(Twy S Twy S5/S6/V1 Twy V) -
 - taxilane Y7 assigned stand.

2.2. TAXIING PROCEDURES OF OTHER AIRCRAFT WHEN THERE IS AIRCRAFT PARKING AT STANDS

Stand 4T

For arriving aircraft

- Stands 23, 24, 26, 27: Aircraft is not allowed to taxi into stands 23, 24, 26, 27.
- Stands 25, 28: After landing, aircraft taxi following the current taxiing procedures into stands 25, 28.
- Remaining stands: Applied the current procedures.

Stand 5T

For arriving aircraft

- Stands 23, 24, 25, 26, 27, 28: Aircraft is not allowed to taxi into stands 23, 24, 25, 26, 27, 28.
- Remaining stands: Applied the current procedures.

Stand 8T

For arriving aircraft

- Stands 35, 36: Aircraft is not allowed to taxi into stands 35, 36.
- Remaining stands: Applied the current procedures, except for taxiing procedures via taxilane Y1 (the portion behind stands 35, 36).

Stand 9T

For arriving aircraft

- Stands 41, 42, 43, 44, 45, 46: Aircraft is not allowed to taxi into stands 41, 42, 43, 44, 45, 46.
- Remaining stands: Applied the current procedures.

Stand 10T

For arriving aircraft

- Stands 42, 43, 45, 46; Aircraft is not allowed to taxi into stands 42, 43, 45, 46.
- Stands 41, 44: After landing, aircraft applied the current taxiing procedures into stands 41, 44.
- Remaining stands: Applied the current procedures.

Stand 11T

For arriving aircraft

- Stands from 47 to 54: Aircraft is not allowed to taxi into stands from 47 to 54.
- Remaining stands: Applied the current procedures.
- Stands 1T, 2T, 3T, 6T, 7T, 12A, 12B, 12T, 13T, 14A, 14B, 16A, 16B,
- For arriving aircraft: Applied the current procedures.

2.3. DISTANCES FROM THRESHOLD TO EXIT TAXIWAYS

2.3.1. Distances from Runway 25R threshold to exit taxiways.

Rwy	Exit Twy	Intersection angle of exit Twy with the Rwy	Distance from threshold to intersection between Rwy centerline and centerline of exit Twy	Remarks
25R	P4	30°	5742'(1750m)	Rapid exit Twy
	P5	30°	6844'(2086m)	Connecting Twy
	Р6	60°	9836′(2998m)	Connecting Twy